


# MODEL LC-X6



\* Projection lens is optional.

# **OWNER'S MANUAL**

### Features and Design

This Multimedia Projector is designed with most advanced technology for portability, durability, and ease of use. This projector utilizes built-in multimedia features, a palette of 16.77 million colors, and matrix liquid crystal display (LCD) technology.

### Compatibility

The projector widely accepts various video and computer input signals including; Analog and Digital Computer sources, 6 TV color systems, Component video, S-video, Digital video sources compatible with HDCP and RGB scart. (IST p37 and 38)

### • Simple Computer System Setting

The projector has the Multi-scan system to conform to almost all computer output signals quickly. The projector accepts signals up to UXGA resolution. (ISP p39 and 72)

### Convenient Fingertip Control Pad

The fingertip Control Pad on the projector's top controls and the remote control provides you a remarkable flexibility and simplicity through the On-Screen Menu navigation. (187 p11, 14, 34, and 35)

### • Easy Menu Operation with USB Mouse

Your USB Mouse Controller can be used for the projector's menu operation. (INST p26, 34, and 35)

### • Vertical and Horizontal Lens Shift and Memory

The projector is equipped with vertical and horizontal Lens Shift and Lens Memory function, which enables you to obtain optimum image easily under various setup environments. (INST p30 and 55)

### One-Touch Removable Filter and Filter LED

One-touch removable filter allows you an easy maintenance and the orange lighting filter LED tells you the best filter exchange timing. (187 p63)

### Advanced Warp & Blending Feature

This feature responds to commercial needs by allowing edge warp and blending correction for projecting image to the spherical and cylindrical screens. With the enclosed Advanced Screen Manager application, you can make correction to the projection image from the computer connected to the projector. (ING p23)

### My Logo

The projector enables you to customize the starting or interval display for your presentation with its image capturing function. (INS p52)

### My Menu Selection

My Menu function allows you to select menu items to be displayed on screen. You can hide menus not in frequent use and make your own menu display. (IPS p51)

### Customized Screen Setting

Fine aspect setting menu is prepared in the projector. You can adjust screen scale and position exactly what you want. (INST p48)

### Shutter Function

The projector is equipped with the shutter that provides complete blackness for a while the projected image is not needed with keeping the projector on. The Shutter management function allows you to set the timer. It prevents leaving the projector on with the shutter released for a long time. ( $\mathbb{R}$  p30, 55 and 56)

### Film Function

The Film function reproduces pictures faithful to the original film quality from 2:3 and 2:2 pull-down video sources. (ING p47)

### Various Security Functions

The following security or anti-theft functions prevent others except users from using the projector: Key Lock, PJ Lock and USB Lock. ( $\mathbb{I}$  p28, 56, and 57)

### Advanced Network Feature

Advanced Network feature available by installation of the optional interface board enables various networking operations including Network Capture, Network Viewer, Network Communication, and Advanced Card Imager. Contact the sales dealer where you purchase the projector for the Advanced Network board. (🖙 p75)

# Table of Contents

Features and Design	2
Table of Contents	3
To The Owner	
Safety Instructions	
Air Circulation	
Setup In Proper Directions	
Moving the Projector	
Caution in Handling the Projector	
Compliance	
Preparation	
Parts Name	
Top Control	
Terminals	
Remote Control	
Remote Control Transmitter	
Remote Control Channel and ID Setup	
Remote Control Battery Installation	
Installation	.18
Installation	
Lens Installation	
Positioning the Projector	.18
Lens Shift Adjustment	
Level Adjustable Feet	.19
Connecting AC Power Cord	.20
Connection Terminals	.21
Interface Board Slots	.21
Connecting to Computer	
(Digital and Analog RGB)	.22
Connecting to Digital PC/AV Equipment	
(Warp & Blending)	.23
Connecting to Video Equipment	0.4
(Digital and Video)	.24
Connecting to Video Equipment (Component and RGB Scart)	25
Basic Operation	
Operating the Projector	
Turning On the Projector	
Turning Off the Projector	
Lens Shift Adjustment	
Zoom and Focus Adjustment	
Shutter Function	
Input Selection	
Auto PC Adjustment	.31
Information	.31
Keystone Adjustment	.32
Screen Selection	
Picture Freeze Function	
P-Timer Function	
D. Zoom +/– Function	.33


Volume Control	33
How to Operate the On-Screen Menu	34
Menu Icons and Their Features	36
Input	37
• Input	
System	
System	
PC System Selection	39
Video or S-Video Signal Selection	40
Component Signal Selection	40
Computer Adjustment	
PC Adjustment	
Auto PC Adjust	41
Manual PC Adjust	42
Image Adjustment	44
Image Adjust	
Screen Setting	
Screen Setting	
Sound	
Sound	
Setting	
Setting	
-	
Special	59
Constal.	<b>F</b> O
Special	
Information	61
Information Maintenance and Cleaning	61 <b>62</b>
Information	
Information	
Information	
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens	
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet	
Information	
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition	61 62 62 63 64 66 66 66 67
Information	
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition Main Indicators Shutter Indicator	61 62 62 63 64 66 66 66 67
Information	61 62 62 63 66 66 66 66 67 67 67 68
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition Main Indicators Shutter Indicator Warning Filter Indicator Lamp Replace Indicators	61 62 63 64 66 66 66 67 67 67 67 68 68 67 63 69
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition Main Indicators Shutter Indicator Warning Filter Indicator Lamp Replace Indicators Appendix	61 62 62 63 66 66 66 66 67 67 67 68 68 69 69 69 69 69 69 69 69 
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition Main Indicators Shutter Indicator Warning Filter Indicator Lamp Replace Indicators	61 62 62 63 64 66 66 66 67 67 68 68 68 69 <b>70</b> 70
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition Main Indicators Shutter Indicator Warning Filter Indicator Lamp Replace Indicators Appendix Troubleshooting	61 62 62 63 64 66 66 66 67 67 67 67 67 67 67 67 67 
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition Main Indicators Shutter Indicator Warning Filter Indicator Lamp Replace Indicators Appendix Troubleshooting Compatible Computer Specifications	61 62 62 63 64 66 66 66 67 67 67 67 67 67 67 63 
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition Main Indicators Shutter Indicator Warning Filter Indicator Lamp Replace Indicators <b>Appendix</b> Troubleshooting Compatible Computer Specifications Technical Specifications	61 62 62 63 66 66 66 66 66 67 67 67 67 67 67 67 67 
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition Main Indicators Shutter Indicator Warning Filter Indicator Lamp Replace Indicators Appendix Troubleshooting Compatible Computer Specifications Optional Parts	61 62 62 63 66 66 66 67 67 67 67 67 68 67 68 67 67 70 70 72 74 75 76
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition Main Indicators Shutter Indicator Warning Filter Indicator Lamp Replace Indicators Appendix Troubleshooting Compatible Computer Specifications Technical Specifications Optional Parts Menu Tree	61 62 63 64 66 66 66 67 67 67 67 67 67 67 67 67 67 67 
Information Maintenance and Cleaning Warning Temp Indicator Air Filter Replacement Lamp Replacement Cleaning the Projection Lens Cleaning the Projector Cabinet Attaching the Cord Cover Strap Indicators and Projector Condition Main Indicators Shutter Indicator Warning Filter Indicator Lamp Replace Indicators Appendix Troubleshooting Compatible Computer Specifications Optional Parts Menu Tree Dimensions	61 62 62 63 66 66 66 66 66 67 67 67 67 68 68 69 70 70 72 74 75 76 79 81

Before operating this projector, read this manual thoroughly and operate the projector properly.

This projector provides many convenient features and functions. Operating the projector properly enables you to manage those features and maintains it in better condition for a considerable time.

Improper operation may result in not only shortening the product-life, but also malfunctions, fire hazard, or other accidents.


If your projector seems to operate improperly, read this manual again, check operations and cable connections and try the solutions in the "Troubleshooting" section in the end of this booklet. If the problem still persists, contact the dealer where you purchased the projector or the service center.





### WARNING : TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

- This projector produces intense light from the projection lens. Do not stare directly into the lens as possible. Eye damage could result. Be especially careful that children do not stare directly into the beam.
- Install the projector in a proper position. If not, it may result in a fire hazard.
- Provide appropriate space on the top, sides and rear of the projector cabinet for allowing air circulation and cooling the projector. Minimum clearance must be maintained. If the projector is to be built into a compartment or similarly enclosed, the minimum distances must be maintained. Do not cover the ventilation slot on the projector. Heat buildup can reduce the service life of your projector, and can also be dangerous.



- Do not put any flammable object or spray can near the projector, hot air is exhausted from the ventilation holes.
- If the projector is not to be used for an extended time, unplug the projector from the power outlet.

## READ AND KEEP THIS OWNER'S MANUAL FOR LATER USE.

### CAUTION

Not for use in a computer room as defined in the Standard for the Protection of Electronic Computer/Data Processing Equipment, ANSI/NFPA 75.

Ne puet être utillisé dans une salle d'ordinateurs telle que définie dans la norme ANSI/NFPA 75 Standard for Protection of Electronic Computer/Data Processing Equipment

#### Trademarks

Each name of corporations or products in this book is either a registered trademark or a trademark of its respective corporation.

#### Remark

Any graphic and figure in this manual are subject to change without notice.

All the safety and operating instructions should be read before the product is operated.

Read all of the instructions given here and retain them for later use. Unplug this projector from AC power supply before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.

Follow all warnings and instructions marked on the projector.

For added protection to the projector during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet. This will prevent damage due to lightning and power line surges.

Do not expose this unit to rain or use near water... for example, in a wet basement, near a swimming pool, etc...

Do not use attachments not recommended by the manufacturer as they may cause hazards.

Do not place this projector on an unstable cart, stand, or table. The projector may fall, causing serious injury to a child or adult, and serious damage to the projector. Use only with a cart or stand recommended by the manufacturer, or sold with the projector. Wall or shelf mounting should follow the manufacturer's instructions, and should use a mounting kit approved by the manufacturers.

An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.



Slots and openings in the back and bottom of the cabinet are provided for ventilation, to ensure reliable operation of the equipment and to protect it from overheating.

The openings should never be covered with cloth or other materials, and the bottom opening should not be blocked by placing the projector on a bed, sofa, rug, or other similar surface. This projector should never be placed near or over a radiator or heat register.

This projector should not be placed in a built-in installation such as a book case unless proper ventilation is provided.

Never push objects of any kind into this projector through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the projector.

Do not install the projector near the ventilation duct of airconditioning equipment. This projector should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied, consult your authorized dealer or local power company.

Do not overload wall outlets and extension cords as this can result in fire or electric shock. Do not allow anything to rest on the power cord. Do not locate this projector where the cord may be damaged by persons walking on it.

Do not attempt to service this projector yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Unplug this projector from wall outlet and refer servicing to qualified service personnel under the following conditions:

- a. When the power cord or plug is damaged or frayed.
- b. If liquid has been spilled into the projector.
- c. If the projector has been exposed to rain or water.
- d. If the projector does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the projector to normal operation.
- e. If the projector has been dropped or the cabinet has been damaged.
- f. When the projector exhibits a distinct change in performance-this indicates a need for service.

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or injury to persons.

Upon completion of any service or repairs to this projector, ask the service technician to perform routine safety checks to determine that the projector is in safe operating condition.



### Voor de klanten in Nederland

Bij dit product zijn batterijen geleverd.

Wanneer deze leeg zijn, moet u ze niet weggooien maar inleveren als KCA.

### Air Circulation


Openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered.

# CAUTION

Hot air is exhausted from the exhaust vent. When using or installing the projector, the following precautions should be taken.

- Do not put any flammable objects near the vent.
- Keep the exhaust vent at least 3'(1m) away from any objects.
- Do not touch a peripheral part of the exhaust vent, especially screws and metallic part. This area will become hot while the projector is being used.
- Do not put anything on the cabinet. The materials put on the cabinet will not only get damaged but also cause fire hazard by heat.

Cooling fans are provided to cool down the projector. This projector monitors internal temperature and control the running speed of the cooling fans.







(Hot air exhaust)



Do not put the projector on either side to project an image.



In upward projection, do not tilt the projector over 20 degrees right and left.




In downward projection, do not tilt the projector over 20 degrees right and left.

### Setup In Proper Directions


Use the projector properly in specified positions. Improper positioning may reduce the lamp life and result in severe accident or fire hazard.

This projector is allowed to project the picture in any position of 360 degrees such as upward, downward, or backward as below.



### **Positioning Precautions**

When installing the projector, avoid positioning it as described below:



20

Do not tilt the projector more than 20 degrees above and below.

### Moving the Projector

Carry the projector by two or more people holding the carrying handle.



Disconnect all the cables from the projector before moving the projector. Moving the projector with the cables connected may cause damage to the projector or result in serious injury.

Retract the projector's adjustable feet and replace the lens cover to protect the lens surface when moving the projector.

### USE CAUTION IN CARRYING OR TRANSPORTING THE PROJECTOR


- Do not drop or bump a projector, otherwise damages or malfunctions may result.
- When carrying a projector, use a suitable carrying case.
- Do not transport a projector by using a courier or transport service in an unsuitable transport case. This may cause damage to a projector. To transport a projector through a courier or transport service, consult your dealer for their information.

REMOVE LENS FROM THE PROJECTOR WHEN CARRYING. OTHERWISE, IT MAY CAUSE SERIOUS DAMAGE TO LENS AND THE PROJECTOR. WHEN TRANSPORT OR STORE THE PROJECTOR WITHOUT LENS, REPLACE THE LENS COVER PLATE INITIALLY ATTACHED TO THE PROJECTOR. TRANSPORTING OR STORING WITHOUT THE LENS COVER PLATE MAY CAUSE DUST TO GET INSIDE THE PROJECTOR AND RESULT IN MALFUNCTION OF THE PROJECTOR OR DAMAGE OF THE OPTICAL COMPONENTS INSIDE THE PROJECTOR.



Carrying Handle

Replace the Lens cover when carrying or not using the projector.




Do not place on an unflat surface and check no object under the cabinet.

Do not hold the terminal cover when lifting or moving the projector, or may cause damage to the terminal cover or result in personal injury.

Do not hold the lens when lifting or moving the projector, or may cause damage to the lens and the projector.

Be sure the surface is flat and no object is under the projector when placing the projector either side up. Uneven surface or any object under the projector may cause damage to its cabinet. Especially be careful of the cabinet area around the exhaust vent.







Do not hold the Lens and the peripheral part.

### Federal Communication Commission Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Do not make any changes or modifications to the equipment unless otherwise specified in the instructions. If such changes or modifications should be made, you could be required to stop operation of the equipment.

### CAUTION

This is a Class A equipment. This equipment can cause interference in residential areas; in this case, the operator can be asked to take adequate countermeasures.

### **AC Power Cord Requirement**

The AC Power Cord supplied with this projector meets the requirement for use in the country you purchased it.

### AC Power Cord for the United States and Canada :


AC Power Cord used in the United States and Canada is listed by the Underwriters Laboratories (UL) and certified by the Canadian Standard Association (CSA).


AC Power Cord has a grounding-type AC line plug. This is a safety feature to be sure that the plug will fit into the power outlet. Do not try to defeat this safety feature. Should you be unable to insert the plug into the outlet, contact your electrician.




THE SOCKET-OUTLET SHOULD BE INSTALLED NEAR THE EQUIPMENT AND EASILY ACCESSIBLE.

### Parts Name







- 1) Remote Receiver
- **2** Projection Lens (Option)
- **③** Front Cover (inside Terminals)
- ④ Speaker
- **(5)** Carrying Handle
- 6 Air Exhaust Vent



Hot air is exhausted from the exhaust vent. Do not put heat-sensitive objects near this side.


# 

This projector is equipped with cooling fans for protection from overheating. Pay attention to following to ensure proper ventilation and avoid a possible risk of fire and malfunction.

- Do not cover vent slots.
- Keep projector sides clear of any objects. Obstructions may block cooling air.
- O Indicators
- $\textcircled{\textbf{8}} \textbf{ Top Controls}$
- (9) Air Intake Vent
- 1 Air Filter (inside)
- 1) Speaker
- 12 Lamp Cover

**13** Adjustable Feet

### Indicators



### 1) LAMP1 REPLACE indicator

Turns orange when the life of the projection lamp1 draws to an end. (p64, 69)

#### **2** WARNING TEMP indicator

Blinks red when the internal temperature of the projector is abnormally high. (p62,67)

### **③** WARNING FILTER indicator

Lights orange when the projector's filter is clogged with dust. (p63, 68)  $\,$ 

#### **④** LAMP indicator

Lights red when the projector is in the stand-by mode, and turns dim lighting when the projector is turned on. (p67)  $\,$ 

#### **5 READY** indicator

Lights green when the projector is ready to be turned on and it remains green lighting while the projector is under operation.

Blinks green in Power Management mode or when the projector is shutdown due to power failure.


### **6** SHUTTER indicator

Lights blue when the shutter is released. (p68)

#### **⑦** LAMP2 REPLACE indicator

Turns orange when the life of the projection lamp2 draws to an end. (p64, 69)

### **Top Control**



### 1 LENS SHIFT button

Activates Lens shift function. (p30)

#### 2 MENU button


Opens or closes the On-Screen Menu. (p34, 35)

### **③** CANCEL button

Cancels the selection and returns to the previous menu.

### (4) Control pad

Navigates through the menu or adjusts value in the On-Screen Menu. These are also used to pan the image in the Digital zoom + mode. (p33, 34, 35)



### About Control Pad

The built-in Control Pad is a semiconductive touchpad operational with light finger touch. Glide your finger up, down, right and left on the pad to go to the desired menu, adjust values and operate various convenient features. Refer to the following pages for respective directions.

- INFO. button
   Displays Information. (p31)
- AUTO PC ADJ. button
   Operates the Auto PC adjustment function. (p31)

### **⑦** INPUT button

Switches input sources. (p31)

### **8** SHUTTER button

Releases and opens up the built-in shutter to block out light. (p30)  $% \left( p_{1}^{2}\right) =\left( p_{1}^{2}\right) \left( p_{1$ 

### **9** POWER ON-OFF button

Turns the projector on or off. (p28, 29)

### **10** SELECT button

Executes the item selected. It is also used to expand/ compress the image in Digital zoom +/- mode. (p33, 34, 35)


### 1 FOCUS button

Adjusts focus of the image. (p30)

#### 2 ZOOM button

Adjusts zoom of the image. (p30)

### Terminals



### 1) INPUT 1 terminals

### AUDIO 1

Connect the audio output from a computer or video equipment connected to DIGITAL (DVI-D) or ANALOG IN terminal to this jack. (p22, 24)

#### DIGITAL (DVI-D) (HDCP compatible)

Connect digital output signal from a computer or video equipment to this terminal with a DVI-D cable. (p22, 24)

#### ANALOG IN

Connect analog output signal from a computer or a video equipment (Component or RGB Scart) to this terminal with a VGA cable, a Scart-VGA or a Component-VGA cable. (p22)

### 2 ANALOG OUT

This terminal can be used for analog signal output incoming through the ANALOG IN terminal (INPUT 1). Connect this terminal to the other monitor with a VGA cable. (p22)

#### **③** INPUT 3 terminals

#### AUDIO (R-L)

Connect the audio output from video equipment connected to VIDEO/Y Cb/Pb Cr/Pr jacks or S-VIDEO jack to these jacks. (When the audio output is monaural, connect it to L(MONO) jack. (p24, 25)

#### VIDEO/Y, Cb/Pb, and Cr/Pr

Connect video or component output (Y, Cb/Pb and Cr/Pr) from video equipment to these jacks with a video cable (RCA-type). (p24, 25)

#### S-VIDEO

Connect S-Video output from video equipment to this jack. (p24)

#### (4) INPUT 2 terminals

#### AUDIO 2


Connect the audio output from video equipment connected to VIDEO/Y, Cb/Pb, and Cr/Pr jacks or G, B, R, H/V, and V jacks to this jack. (p22, 25)

#### VIDEO/Y, Cb/Pb, and Cr/Pr

Connect video or component output (Y, Cb/Pb and Cr/Pr) from video equipment to these jacks with a video cable (BNC-type). (p25)

#### G, B, R, H/V, and V

Connect RGB output signal from a computer with a computer cable (5 BNC-type) to these jacks. (p22)



### 1) INPUT 4 (WARP & BLENDING board)

### **DIGITAL (DVI-D) (HDCP compatible)**

Connect digital output signal from a computer or video equipment to this terminal with a DVI-D cable. (p23)

#### **SERIAL PORT IN**

When operating Warp and Blending feature, connect serial port of the computer and this terminal with a serial cross cable (commercially supplied). (p23)

#### SERIAL PORT OUT

When using Warp and Blending feature for more than two projectors from a computer connected to the SERIAL PORT IN terminal above, connect SERIAL PORT IN terminal on the other projector and this terminal with a serial cross cable (commercially supplied). (p23)

### ✔ Note:

Refer to the enclosed operation manual for Warp and Blending in Advanced Screen Manager.

### **②** INPUT 5 (Vacant for Optional Interface Board)

Optional interface board can be installed into this slot. This input accepts digital signals only. (p21, 75)

A built-in micro processor which controls this unit may occasionally malfunction and need to be reset. This can be done by pressing the RESET button with a pen, which will shut down and restart the unit. Do not use the RESET function excessively.

### 3 R/C JACK

Connect the remote control to this jack with the supplied remote control cable to use the remote control as wired. (p26)

### ④ USB

Connect a USB mouse (commercially available) to control On-Screen Menu.  $\ensuremath{\left( p26 \right)}$ 

### **5** USB (Series B)

This port is used for the projector maintenance.


### **6** SERIAL PORT OUT

This terminal outputs signal from SERIAL PORT IN. When controling more than two projectors from a computer, connect the other projector to this terminal with a serial cross cable (commercially supplied).

### **⑦** SERIAL PORT IN

When controling the projector from a computer, connect the computer to this terminal with a serial cross cable (commercially supplied).

### **Remote Control**



#### $\textcircled{1} \quad \text{SHUTTER button} \quad$

Releases the built-in shutter for light blocking. (p30)

- **KEYSTONE button** Corrects keystone distortion. (p32)
- ③ LENS SHIFT button Activates LENS SHIFT function. (p30)
- CONTROL PAD (semiconductive touchpad) Selects an item or adjusts value in the On-Screen Menu. This is also used to pan the image in the Digital zoom + mode. (p33)


### **5 WIRED REMOTE JACK**

Connect the Remote Control Cable to this jack. Battery installation is required regardless if it is used as wired or wireless. (p16, 26)

- (6) D.ZOOM button Activates D.Zoom +/- function. (p33)
- POWER ON-OFF button Turns the projector on or off. (p28, 29)
- (8) FOCUS buttons Adjust focus of the image. (p30)
- (9) **ZOOM buttons** Adjust zoom of the image. (p30)
- 10 SELECT button

Executes the item selected.

Preparation



① MENU button

Opens or closes the On-Screen Menu. (p34, 35)

- FREEZE button
   Freezes the projected picture. (p32)
- 3 VOL. button Adjusts volume. (p33)
- (4) MUTE button Mutes sound. (p33)
- **5** CH button

Switches Remote Control Channel (CH). (p16)

6 ID button

Switches Remote Control ID. (p16)

### ⑦ P-TIMER button

Operates P-Timer function. (p32)

**8** CANCEL button

Cancels the selection and returns to the previous menu. (p34)

- INFO button
   Displays the projector information. (p31)
- AUTO PC button
   Operates the Auto PC adjustment. (p31)
- SCREEN button Selects screen sizes. (p32)
- INPUT 1-3 buttons Selects input source (INPUT 1 - INPUT 3). (p31)
- 13 INPUT 4-5 buttons Selects input source (INPUT 4 - INPUT 5). (p31)

### **1 REMOTE RESET/ON/ALL-OFF switch**


When using the remote control, set this switch to "ON." Set it to "ALL OFF" for power saving when it is not used. Slide this switch to "RESET" with holding down the CH and ID buttons at the same time to initialize the Remote Control ID and CH. (p16)

### Remote Control Transmitter

This wireless remote control uses radio frequency signal. You can switch four frequency channels prepared and select a remote control ID from eight IDs. The Remote Control Channel selection prevents radio frequency interference from the other equipment and the Remote Control ID selection allows you to operate several projectors with their respective remote controls without mutual interference among those projectors.

### Wired Remote Control Transmitter

The remote control can be used as a wired remote control. When interference between the projector and other equipment occurs or the projector is used in a place where the operation of radio equipment is restricted, connect the remote control and the projector with the remote control cable provided. Connected with the remote control cable, the remote control does not emit radio signal.



### **Remote Control Channel and ID Setup**

Initial Remote Control Channel and ID are CH1 and ID1. When you change the setting, set a Channel first, and then an ID.

Channel and ID settings for the remote control should be the same as those for the projector. When changing the CH and ID settings to the remote control, do it to the projector as well. Refer to "Remote Control " in Setting menu on page 53.

Should you be lost at which CH and ID are currently set, initialize the Channel and ID once, and set them again.

### 1 Set the Remote Control Channel

With holding down the CH button, press the SELECT button. The Remote Control Channel switches sequentially for one pressing the SELECT button. (See Table1 on next page.)

### 2 Set the Remote Control ID


With holding down the ID button, press the SELECT button. The Remote Control ID switches sequentially for one pressing the SELECT button. (See Table2 on next page.)


### Initialize the Remote Control Channel and ID

With holding down the CH and ID buttons together, slide the REMOTE RESET/ON/ALL-OFF switch to REMOTE RESET, and then to ON. The initial Channel and ID are CH1 and ID1. (p15)

### ✔Note:

Remote Control Channel and ID cannot be initialized separately.





Preparation

Remote Control CH	Radio Frequency
CH 1 *	2.472 GHz
CH 2	2.403 GHz
CH 3	2.446 GHz
CH 4	2.421GHz

Table1: Remote Control Channel & Frequency

Channel switches sequentially for one pressing the SELECT button.

y for ton. Remote Control ID

Remote Control ID	t l
ID 1 *	
ID 2	
ID 3	
ID 4	
ID 5	
ID 6	
ID 7	
ID 8	

**Table2: Remote Control ID** 

Channel switches sequentially for one pressing the SELECT button.

/

\* Default setting

### **Caution about Radio Wave**

The remote control operates in 2.4 GHz band, the same frequency band used for industrial, scientific, and medical equipment (such as pacemaker), as well as amateur radio stations.

Before operating the remote control, make sure no electromagnetic interference occurs and pay attention to the following cautions.


- 1. Be sure that there are no other devices in the area that may use the same frequency band as the remote control.
- 2. If any other devices are causing radio interferences, change the communication frequency channel or move to other location.

### **Caution in Wireless LAN Interference**

Under wireless LAN environment based on IEEE 802.11b and IEEE802.11g, the remote control may not operate properly due to radio interferences. The remote control is initially set to use 2.472 GHz band (CH1) corresponding to several channels of wireless LAN.

Should the remote control not operate properly due to radio interference, switch the communication frequency channel to CH2. Yet the operating condition is not improved, try CH3 and CH4. In case of failure in every channel operation, relocate other radio equipment using 2.4 GHz band away from the remote control and the projector.

### Remote Control Battery Installation



### Installation

Install the projector in a safe place. Before installation, read Safety Instructions thoroughly and check the installation place. Install the projector in a place with sufficient strength to support the projector's weight. Installation on an unstable stand, cart, or ceiling may cause serious injury or accidents.

Do not place the projector where is extremely hot and humid. Do not place the projector where is dusty and smoky. When installing the projector in dusty and smoky places or in a place for a long period of time, installation with Smoke Resist Box (AH-69601) separately supplied is recommended. (p75)

### Lens Installation


Before setting up the projector, install optional lens in the projector. Install the lens following the instructions in the Lens Installation Manual provided. Ask the sales dealer for detailed information of optional lens specifications.

Do not move the projector with holding the lens mounted and its peripheral part. It may cause serious damages to the projector and the lens.



When moving or setting up the projector, check the followings again:


- Be sure that the lens is securely installed into the projector.
- Be sure to replace Lens cap to protect lens surface.
- Be careful not to hold or subject a lens to strong forces. It may damage lens, cabinet, or mechanical parts.



### Positioning the Projector

This projector is designed to project on a flat surface. Projector should be perpendicular to the projection screen. Otherwise, the projected image may be distorted. Keystone function allows you to correct image distortions, but it should be considered that the keystone correction may lower the image resolution. (p32)


Do not expose the projection screen to direct sunlight or excessive ambient lighting. The projected image may get whitetinged due to reflection and the best image quality may not be obtained.



### Lens Shift Adjustment

Lens shift feature is provided to move the position of the projected image vertically by 50% and horizontally by 10% respectively without any image distortion.

\* Lens shift range varies depending on lens and projectors. The range in this manual is the case of LNS-W04.





### Level Adjustable Feet

This projector has four level adjustable feet. The projection angle can be adjusted by rotating each foot. Adjust the four feet to obtain best position of the projected image and make the projector stable.

The projection angle is adjustable up to 3.65 degrees upward and downward respectively by rotating front and back feet.

The projector can project image vertically and horizontally in the range of 360 degrees. For proper installation, refer to Setup In Proper Directions on page 6.





Projection angle is adjustable up to 3.65 degrees upward and 3.65 degrees downward by adjusting front and back feet.

### **Connecting AC Power Cord**

CAUTION

This projector uses nominal input voltages of 120 V or 200-240 V AC. This projector automatically selects correct input voltage. It is designed to work with single-phase power systems having a grounded neutral conductor. To reduce risk of electrical shock, do not plug into any other type of power system.

Consult your authorized dealer or service station if you are not sure of type of the power being supplied.


Connect a projector with peripheral equipment before turning on it. (Refer to  $p22 \sim 25$  for connection.)

For safety, unplug AC power cord when the projector is not in

use. When this projector is connected to an outlet with AC


power cord and the Main On/Off switch is on, the projector is in

stand-by mode and consumes a little electric power.



#### AC power socket

Connect AC Power Cord (supplied) to this socket. AC outlet must be near this equipment and must be easily accessible.




### **Connection Terminals**

Terminals to connect AC power cord and other equipment are located in the front part of the projector for easy setup. The terminal area is masked with the front cover to protect them from dust and others, and hide messy cable connections.


Remove and replace the front cover following the procedure below:

Pushing the button **A** on right side of the front cover, pull the part forward to remove the front cover.

To replace the front cover onto the projector, insert back the left part of the cover into the projector and then push the entire cover back the projector. Make sure the front cover is locked with the button  $\bf{A}$  and fit on the projector.



Pull this part forward with pushing button **A**.



Terminals



Caution

Do not push hard or give a strong shock to the cover. It may cause damage to it.

### Interface Board Slots

The projector's front terminal area has two replaceable Interface board slots. The projector's functions can be extended by installing the optional interface boards into the terminal slots. A vacant slot (Input 5) is provided in your purchasing the projector.

Install or replace the optional interface boards as follows:

Remove 2 screws from an interface board installed in the projector.


Pull out the interface board by holding its handles and remove it. Then, insert another board along with the guides inside the slot to fit the socket into the inside plug. Tighten screws to secure the board.

### Note:

When installing or removing the interface board, disconnect the AC power cord from the AC outlet before doing it.


#### ✓ Notes On Ordering or Using Optional Interface Boards:

When ordering or using the Optional Interface Boards, contact your sales dealer and tell the Model no. of your desired board (p75) and Option Control No. shown in the Information menu. (p3 I and 6 I)



Screws

### **Option Control No.**



See Option Control No. in the Information menu to order any optional interface board.

Installation

### Connecting to Computer (Digital and Analog RGB)


(5) Audio Cables (Mini Plug: stereo) \*

(\* = Not supplied with this projector.)

### **Cables used for connection**

VGA Cable (HDB 15 pin)
 DVI-D Cable
 BNC Cable \*

Serial Cross Cable (RS-232C) \*



Note:


When connecting the cable, the power cords of both the projector and the external equipment should be disconnected from AC outlet.

### Connecting to Digital PC/AV Equipment (Warp & Blending)

### **Cables used for connection**

DVI-D Cable
 Serial Cross Cables (RS-232C) \*
 (\* = Not supplied with this projector.)

Refer to the enclosed operation manual for details in operation of the Warp & Blending feature.



### Note:

Connect digital PC/AV source to the DIGITAL (DVI-D) terminal with a DVI-D cable to adjust projected images from the computer connected to the SERIAL PORT IN terminal with Warp and Blending feature.



Note:

When connecting the cable, the power cords of both the projector and the external equipment should be disconnected from AC outlet.


### Connecting to Video Equipment (Digital and Video)

**Cables used for connection** 

 Video Cable \* 2 S-Video Cable \*

3 DVI-D Cable

(4) Audio Cables (RCA x 2, Mini Plug: stereo) \* (\* = Not supplied with this projector.)






Note: When connecting the cable, the power cords of both the projector and the external equipment should be disconnected from AC outlet.

### Connecting to Video Equipment (Component and RGB Scart)

### **Cables used for connection**

① BNC Cable \*

- ② Scart-VGA Cable \*
- ③ Component Cable \*
- (4) Audio Cables (Mini Plug (stereo) + RCA x 2, or RCA x 1) \*
- (\* = Not supplied with this projector.)





Note:


When connecting the cable, the power cords of both the projector and the external equipment should be disconnected from AC outlet.

### **Operating the Projector**


You can operate the projector with the projector's top control, the remote control or a USB mouse (not provided). The remote control is available as wireless and wired.

Operational range of the wireless remote control is within about 32.8' (10m) from the projector. Operational range differs depending on environments where the projector is used. Any obstruction to air signal between the projector and the remote control may prevent the remote control from working properly.

#### Wireless Remote Control Operation




#### Wired Remote Control Operation



Connect the R/C JACK on the projector and the remote control with the remote control cable when operating the remote control as wired.

#### **Mouse Operation**




Connect the USB terminal on the projector and a USB mouse when operating the projector's menu with the USB mouse. A mouse cursor will appear on the screen with the mouse connected.

Mouse operation offers the On-Screen Menu control only. Other operations are unavailable with the USB mouse. For details of the mouse operation, refer to page 34~35.



The wireless remote control does not work when the remote control cable is connected to either the projector or the remote control. Remove the remote control cable from both of the projector and the remote control when using it as wireless.

#### **Projector Top Control Operation**



## **Basic Operation and Reference Buttons**

For detail operations other than those on this page, follow the respective menu operations described later.

<b>Operations &amp; Buttons</b>	Top Control         Image: Im	Remote Control	Ref. Pages
On-Off	0	0	28, 29
Lens Shift	$\bigcirc \rightarrow \square$	$\bigcirc \rightarrow $ Pad	30
Zoom	$\bigcirc \rightarrow $ Pad	○ (▲▼)	30
Focus	$\bigcirc \rightarrow \square$	○ (▲▼)	30
Shutter	0	0	30, 55
Auto PC Adjust	0	0	31, 41
Input Selection	0	🔵 (Input 1–5)	31, 37~38
Information	0	0	31, 61
Keystone	_	$\bigcirc \rightarrow \square$	32, 49
Screen Selection	-	0	32, 48
Freeze	_	0	32
P-Timer	_	0	32
D. Zoom	_	$\bigcirc \rightarrow \square$	33, 49
Remote CH and ID	_	0	16, 17
Volume	-	$\bigcirc \rightarrow $ $\bigcirc$ Pad	33
Mute	_	0	33
Menu	0	0	34~36
Select	0	0	
Cancel	These buttons are used on the menu operations.	O These buttons are used on the menu operations.	

### Turning On the Projector

- Complete peripheral connections (with Computer, VCR, etc.) before turning on the projector. (Refer to page 22~25 for connection.)
- 2 Turn on the MAIN On/Off switch of the projector. The LAMP indicator lights red, and the READY indicator lights green.
- **3** Press the POWER ON-OFF button on the top control or the remote control. The LAMP indicator dims, and the cooling fans start to operate. The preparation display appears on the screen and count-down starts. The input and source selected last appears after 20 seconds count-down.

If the projector is locked with a PJ PIN code, PJ PIN code Input Dialog Box will appear. Enter the PIN code as instructed below.

### Enter a PJ PIN code

Select a number by softly tapping the control pad and fix the number with the SELECT button. The number will change to "\*". If you fixed a wrong number, move the yellow frame pointer to "C" or "Ent" once, then enter the correct number again.

Repeat this step to complete entering a four-digit number.

When the four-digit number is fixed, move the yellow frame pointer to "Ent". Press the SELECT button so that you can start to operate the projector.

If you entered a wrong PIN code, the entered number (\*\*\*\*\*) will turn red and disappear. Enter a correct PIN code all over again.

### What is PIN code?

PIN code is a security code using Personal Identification Number that allows the person who knows it to operate the projector. Setting PIN code prevents the projector from being operated by an unauthorized person.

A PIN code consists of a four-digit number. Refer to Security in Setting on page 57 for locking operation of the projector with your PIN code.




#### CAUTION ON HANDLING PIN CODE

If you forget your PIN code, the projector can no longer be started. Set a new PIN code with special care, write it down in column on page 81 of this manual, and keep it at hand. Should the PIN code be missing or forgotten, consult your sales dealer or the service station.




The preparation display disappears after 20 seconds.

#### Selected Input and Source



(See page 37~38 for Input)





### Turning Off the Projector

- Press the POWER ON-OFF button on the top control or the remote control, and a message "Power off?" appears on the screen.
- Press the POWER ON-OFF button again to turn off the projector. The LAMP indicator brightly lights red and the READY indicator goes out. After approximate 90 seconds, the READY indicator will light green again and then the projector can be turned on by pressing the POWER ON-OFF button.
- **3** The Cooling fans operate for approximate 2 minutes after the projector is turned off; keep operating more 30 seconds after the READY indicator lights green. To power down the projector completely, turn off the MAIN On/Off switch and disconnect the AC Power Cord.



TO MAINTAIN THE LIFE OF LAMP, ONCE YOU TURN PROJECTOR ON, WAIT AT LEAST 5 MINUTES BEFORE TURNING IT OFF.

DO NOT DISCONNECT AC POWER CORD WHILE COOLING FANS ARE RUNNING OR BEFORE POWER INDICATOR LIGHTS RED. OTHERWISE IT WILL RESULT IN SHORTENING LAMP LIFE.

### Note:


- The projector cannot be turned on for about 90 seconds after turned off. You can turn it on again after the READY indicator lights green.
- When the On start function is on, this projector is turned on automatically by connecting the AC power cord to an AC outlet. (See page 54 for the On start function.)
- Do not operate the projector continuously without rest. Continuous use may result in shortening the lamp life. Turn off the projector and give it a rest about an hour in every 24 hours.
- This projector monitors internal temperature and automatically controls the running speed of the cooling fans.
- If the WARNING TEMP indicator blinks red or all the indicators except the LAMP indicator are blinking, see "Warning Temp Indicator" on page 62.
- When "Power management" mode is Ready or Shut down, projector detects signal interruption and turns off the Projection Lamp automatically after the set time has passed. Refer to "Power management" on page 54.



The message disappears after 4 seconds.

### Lens Shift Adjustment

Press the LENS SHIFT button and adjust with the Control pad.



Zoom

- When the lens position comes right in center vertically, the vertical arrows turn red.
- When the lens position comes right in center horizontally, the horizontal arrows turn red.

### Zoom and Focus Adjustment

### **Top Control**

Press the ZOOM/FOCUS button and adjust with the Control pad.


### **Remote Control**

Press the ZOOM/FOCUS ▲▼ button to adjust Zoom and Focus.

### Shutter Function


Shutter function allows you to completely block out light to the screen. Press the SHUTTER button to release the shutter inside the projector. To open up the shutter, press the SHUTTER button again. Refer to  $p55\sim56$  for detail of setting for the Shutter function.

**Remote Control** 



SHUTTER button

#### **Top Control**




### Note:

- The SHUTTER buttons on the top control and the remote control can not be effective when Shutter Protection is "On" in the Setting menu. (p55)
- The SHUTTER indicator on the projector's top lights blue when the shutter is released. (p10)
- When the Shutter level is "High contrast" in the Setting menu, the shutter opens up 80%. (p55)
- The projector will shut down automatically when the set time on Shutter management has passed. (p56)

### Input Selection

Choose either Input 1, Input 2, Input 3, Input 4, or Input 5 by pressing the INPUT button on the top control or the INPUT 1, INPUT 2, INPUT 3, INPUT 4, or INPUT 5 button on the remote control.

Before using these buttons, correct input source should be selected through menu operation as described on p37~38.



### Auto PC Adjustment

Auto PC Adjustment function is provided to automatically adjust Fine sync, Total dots, Horizontal, and Vertical picture position to conform to your computer by just pressing the AUTO PC ADJ. on the top control or the AUTO PC button on the remote control.

### Note:


- Fine sync, Total dots and Picture Position of some computers can not be fully adjusted with this Auto PC Adjustment function. When the image is not provided properly with this operation, manual adjustments are required. (p42, 43)
- Auto PC Adjustment function cannot be operated in Digital Signal input on DVI terminal and "480i", "575i", "480p", "575p", "720p (HDTV)", "1035i (HDTV)", "1080i/50 (HDTV)" or "1080i/60 (HDTV)" is selected on System menu (P40).

### Information

Information display can be used to confirm the current operating condition of the projector and the signal being projected through the projector.

Press the INFO button to display Information window on screen. To hide the Information window, press the INFO button again.

Use this menu to check the projector's operating condition when you face troubles in operation. Refer to the Information menu on page 61.



### Keystone Adjustment

Keystone function is provided to correct image distortions. Press the KEYSTONE button and correct vertical and horizontal distortions with the Control pad. The Keystone adjustment can be memorized. (p49)




- The arrows are white when there is no correction.
- The arrows disappear at the maximum correction.
- The direction of the arrow being corrected turns red.
- If you press the KEYSTONE button on the remote control once again while the keystone dialog box is being displayed, the keystone adjustment will be canceled.

### Screen Selection

Select a screen size among Normal, Wide, True, Full screen and Custom by pressing the SCREEN button on the remote control. Refer to the Screen menu on p48 for details of each screen setting.

### ✔Note:

True and Full screen cannot be selected when selecting AV sources for the Input.



### Picture Freeze Function

Press the FREEZE button on the remote control to freeze the picture on screen. To cancel the Freeze function, press the FREEZE button again or press any other button.

### **P-Timer Function**

Press the P-TIMER button on the remote control. The timer display "00 : 00" appears on the screen and the timer starts to count time (00 :  $00 \sim 59 : 59$ ).

To stop the P-Timer, press the P-TIMER button. And then, press the P-TIMER button again to cancel the P-Timer function.



### D. Zoom +/- Function

### D. Zoom +

Press the D. ZOOM button on the remote control once and then expand the image size with the SELECT button and pan the image with the Control pad.

### D. Zoom –

Press the D. ZOOM button on the remote control twice and then compress the image size with the SELECT button.

### ✔Note:

To exit the D. Zoom +/- mode, try the followings:

- To return to the normal screen, change Input, or change the screen size.
- To exit the panning mode, press any button except the D. ZOOM button, the SELECT button, and the CH and ID buttons.

D. Zoom +


### Volume Control

### Volume

Press the VOL button on the remote control. The volume dialog box appears on screen. Adjust volume with the Control pad.

### Mute

Press the MUTE button on the remote control to cut off sound. To restore sound to its previous level, press the MUTE button again or press the VOL button and change volume level with the Control pad.



Press the MUTE button to set the Mute function On or Off.

The display disappears after 4 seconds.

### How to Operate the On-Screen Menu

The projector can be adjusted or set via the On-Screen Menu. Refer to the following pages for respective adjustment and setting procedure.


### **Top Control/Remote Control Operation**

- *1* Press the MENU button on the projector's top control or the remote control to display the On-Screen Menu.
- 2 Softly tap the Control pad on the top control or the remote control to spin Menu icons. When a desired Menu icon comes right in front, press the SELECT button to display Sub-menu.
- **3** Select an item to adjust by softly tapping the Control pad or gliding your finger on the Control pad.
- **4** Press the SELECT button to show the item data. Adjust the data or select a desired setting by your fingertip operation on the Control pad.

#### Note:


- The selected item is not in effect until the SELECT button is pressed.
- To return to the previous menu or cancel the selection, press the CANCEL button.

### Top Control



**Control pad** 

### **Remote Control**



### **Mouse Operation**

- 1 Left click your mouse to display the On-Screen Menu.
- 2 Select a Menu icon with the mouse pointer and one left click to display the submenu or with clicking ◀▶ or ◀◀▶▶ to spin Menu icons and click ENTER when a desired Menu icon is right in front.
- **3** Click an item to show the item data to adjust or the dialog box to select a setting.
- 4 Adjust the data with clicking ▲▼ or moving up or down the right bar or click a desired setting.

### Note:

To return to the previous menu or cancel the selection, right click your mouse.

### **On-Screen Menu**

SCREEN SETTING	Menu icon Guide Currently selected menu.
	<ul> <li>Control bar for Mouse Operation</li> <li>This bar appears when a USB mouse is connected to the USB terminal of the projector.</li> </ul>
SELECT button	<ul> <li>Mouse cursor</li> <li>When clicking on ◄ or ▶ on the control bar, menu icons rotate fast. When clicking on ◄ or ▶, menu icons rotate one by one by every left clicking.</li> <li>When a desired Menu icon comes right in front, click SELECT or press the SELECT button on the remote control or the top control.</li> </ul>
D.Zoom	Pointer (yellow frame) Move the pointer to select an item with the Control pad and press the SELECT button or by mouse clicking. The selected item box will turn yellow. - Navigate through items with the Control pad or the mouse cursor and the next menu will automatically be displayed.
Keystone	ue Item data Click the Point ▲▼ or move the bar to adjust value.
Quit       Item     To exit this menu.	Aspect Scale H 0 V 0 H&V 0
✓ Note: The Control bar for mouse operation and the Mouse cursor do no appear with no USB mouse connected to the projector.	Position H 0 V 0 Common Reset

### Menu Icons and Their Features

The projector can be adjusted or set via the On-Screen Menu. Refer to the following pages for respective adjustment and setting procedure.


Menu icons		What You Can Do with Each Menu	Page no.
5	INPUT :	selects input sources. Before selecting input sources with the top control or the remote control, correct input source should be selected through menu operation.	37~38
	SYSTEM :	selects system of the connected computer and video sources.	39~40
	PC ADJ. :	adjusts several features precisely for the projector to conform to your computer's signal format and project optimum image.	41~43
	IMAGE :	selects image levels suitable for the connected image source and allows you to select the image data stored in Image Adjust Menu.	44
K	IMAGE ADJ. :	adjusts each picture component of the projected image in detail and store the adjusted image data in the projector to reproduce the customized image quality anytime.	45~47
$\dot{\dot{}}$	SCREEN SETTING :	selects screen aspect, adjusts vertical and horizontal scales, picture position, sets the projection method (Ceiling and Rear), and activates keystone and digital zoom functions.	48~49
	SOUND :	adjusts sound that the projector's speakers reproduce.	50
J/	SETTING :	sets up operating environment for various features of the projector.	51~58
	SPECIAL :	sets up operating environment of the projector and serves to the projector's maintenance.	59~61
	INFORMATION :	displays current setting information and operating conditions of the projector, and allows you to check under what condition the projector is operating.	61

### Input



- Press the MENU button to display the On-Screen Menu. Spin the menu icons with the Control pad and press the SELECT button when the INPUT icon comes right in front.
- 2 Move the yellow frame pointer with the Control pad to a input which you want to select.
- 3 Press the SELECT button to display Source Select Menu for the input selected. Select a source from the Source Select Menu.

Input Menu



#### -Input icon

Move the pointer (yellow frame) to an input that you want to select and press the SELECT button.

The item being selected.

#### Input 1

Move a pointer to Input 1 and press the SELECT button.

RGB (PC Analog)	When the input source is analog coming from a
	computer through the Input 1 (ANALOG IN)
	terminal, select RGB (PC Analog).

**RGB (Scart)** When the input source is coming from video equipment connected to the Input 1 (ANALOG IN) terminal with a Scart-VGA Cable, select RGB (Scart).

- **RGB (PC Digital)** When the input source is digital coming from a computer through the Input 1 (DVI) terminal, select RGB (PC Digital)
- **RGB (AV HDCP)** When the input source compatible with HDCP is coming from video equipment through the Input 1 (DVI) terminal, select RGB (AV HDCP).

#### Note:

HDCP (High-bandwidth Digital Content Protection) is a system for protecting digital entertainment content delivered by DVI (Digital Visual Interface) from being copied. The specification of HDCP is decided and controlled by Digital Content Protection, LLC. Should the specification be changed, this projector may not display the digital content protected by HDCP.



Input 1

Input 2

Input 3


Input 4

Input 5

Quit



Move the pointer to RGB(PC Analog), RGB (Scart), RGB(PC Digital), or RGB(AV HDCP) and press the SELECT button.



#### Input 2

Move a pointer to Input 2 and press the SELECT button.

RGB	When the input source is analog coming from a computer through the Input 2 (5 BNC-type: Red, Green, Blue, H. Sync. and V. Sync.) terminal, select RGB.
Video	When video input signal is connected to the Input 2 (VIDEO) terminal , select Video.
Y, Pb/Cb, Pr/Cr	When the input source is component coming from video equipment connected

select Y, Pb/Cb, Pr/Cr.

select Y, Pb/Cb, Pr/Cr.

Move a pointer to Input 3 and press the SELECT button.

to the Input 2 (Y, Pb/Cb, Pr/Cr) terminal,

When video input signal is connected to the

When the input source is component


coming from video equipment connected

to the Input 3 (Y, Pb/Cb, Pr/Cr) terminal,

When video input signal is connected to the

Input 3 (S-VIDEO) terminal, select S-Video.


Input 3 (VIDEO) terminal, select Video.



Source Select Menu

Move the pointer to RGB, Video or Y, Pb/Cb, Pr/Cr and press the SELECT button.





#### Source Select Menu

Move the pointer to Video, Y, Pb/Cb, Pr/Cr or S-Video and press the SELECT button.

· .	
nput 3	
nput 4	Video
nput 5	Y, Pb/Cb, Pr/Cr
Quit	S-Video

# Input 4

Input 3

Video

Y, Pb/Cb, Pr/Cr

S-Video

When digital PC/AV source is connected to the Warp & Blending board inserted into the Input 4 terminal, the following source menu will be displayed.



When the input source compatible with HDCP is coming from video equipment through the Input 4 (DVI) terminal, select RGB (AV HDCP).

#### Note:

Warp & Blending board is initially installed into the Input 4 terminal slot. For details on Warp & Blending feature, refer to the enclosed operation manual.

#### Input 5

A source menu appears corresponding to the board module inserted into the Input 5 terminal.

#### Note:

- Input 4 and Input 5 can not be selected when no interface board is inserted into the respective slots. (p21)
- Input 5 terminal can only accept digital signals.
- Adjusted values or selected settings in Input 4 and Input 5 return to factory default setting when the connected interface boards are removed from those terminal slots.



selects system of the connected computer and video source.

#### **PC System Selection**

Svstem

#### Auto

This projector automatically tunes to various types of computers based on VGA, SVGA, XGA, SXGA or UXGA with its Multi-scan system and Auto PC Adjustment. If Computer source is selected in the Source Select Menu, this projector automatically detects the signal format and tunes to project a proper image without any additional setting. (Signal formats provided in this projector is shown on page 72~73)

#### Note:

The projector may display one of the following messages.



-----

PC Systems provided in the projector. The projector chooses a proper system and displays it.

- There is no signal input from computer. Check the connection of your computer and the projector. (See "Troubleshooting" p70)
- Mode 1 User preset system manually adjusted in PC Adjust menu. Adjustment data can be stored in Mode 1–50. (p42~43)


\*SVGA 1 and Mode 1 are examples.

#### Selecting PC System Manually

When the projector has difficulty in recognizing the connected signal conforming to PC Systems provided in this projector, several systems are displayed. Select one from them manually. When the image is not projected properly, manual adjustment is required. (p42~43)

- **1** Press the MENU button to display On-Screen Menu. Spin the menu icons with the Control pad and press the SELECT button when the SYSTEM icon comes right in front.
- 2 Move the yellow frame pointer with the Control pad to a proper system, and then press the SELECT button.

#### PC System Menu



The system being selected.

#### Video or S-Video Signal Selection

#### Auto

The projector automatically detects incoming video system, and adjusts itself to optimize its performance. When Video System is PAL-M or PAL-N, select system manually.


#### PAL / SECAM / NTSC / NTSC4.43 / PAL-M / PAL-N

If the projector cannot reproduce proper video image, it is necessary to select a specific broadcast signal format among PAL, SECAM, NTSC, NTSC 4.43, PAL-M, and PAL-N.

#### Note:

When Auto is selected for the System menu, PAL-M and PAL-N cannot be selected.

#### AV System Menu (Video or S-Video)



Move the yellow frame pointer to a system and press the SELECT button to activate it.

#### **AV System Menu (Component)**




#### Auto

The projector automatically detects incoming video signal, and adjusts itself to optimize its performance.

#### COMPONENT VIDEO SIGNAL FORMAT

If the projector cannot reproduce proper video image, it is necessary to select a specific component video signal format among 480i, 575i, 480p, 575p, 720p, 1035i, and 1080i.



Move the pointer to a system and press the SELECT button to activate it.



selects Auto PC Adj., Fine sync, Total dots, Current mode, Clamp, Display area, Position, V-sync phase, Reset, and Mode.

#### **Auto PC Adjust**


#### Auto PC adj.

- Press the MENU button to display On-Screen Menu. Spin 1 the menu icons with the Control pad and press the SELECT button when the PC ADJ. icon comes right in front.
- Move the yellow frame pointer to Auto PC adj. and then 2 press the SELECT button twice. This Auto PC Adjustment can be also executed by pressing the AUTO PC ADJ. button on the top control or the AUTO PC button on the remote control unit. (p15, 31)

#### To store adjustment parameters

Adjustment parameters from Auto PC Adjustment can be memorized in this projector. Once parameters are memorized, the setting can be done just by selecting Mode in the System menu (p39). See Store on page 43.

#### PC Adjust Menu



Move the yellow frame pointer to the Auto PC adj. and

#### Note:


- Fine sync, Total dots and Picture Position of some computers can not be fully adjusted with this Auto PC Adjustment function. When the image is not provided properly with this operation, manual adjustments are required. (p42, 43)
- Auto PC Adjustment function cannot be operated in Digital Signal input on DVI terminal and "480i", "575i", "480p", "575p", "720p (HDTV)", "1035i (HDTV)", "I 080i/50 (HDTV)" or "I 080i/60 (HDTV)" is selected on the System menu (p40).

#### **Manual PC Adjust**

Some computers employ special signal formats which may not be tuned by Multi-scan system of this projector. Manual PC Adjustment enables you to precisely adjust several parameters to match those signal formats. The projector has 50 independent memory areas to memorize those parameters adjusted manually. It allows you to recall the setting for a specific computer easily.

- Press the MENU button to display On-Screen Menu. Spin the menu icons with the Control pad and press the SELECT button when the PC ADJ. icon comes right in front.
- 2 Move the yellow frame pointer with the Control pad to an item which you want to select.
- **3** Press the SELECT button to display an adjustment dialog box. Adjust value with the Control pad.

#### PC Adjust Menu



Move the yellow frame pointer to an item and press the SELECT button.

#### Fine sync

Eliminates flicker from the image displayed. Adjust value with the Control pad. (From 0 to 31)

#### Total dots

Adjusts the number of total dots in one horizontal period. Adjust number to match your PC image with the Control pad.

#### Current mode

Press the SELECT button to show H-Freq. and V-Freq. of the connected computer.

#### Clamp

Adjusts clamp level (Phase and Width). When the image has dark bars, try this adjustment.

#### Display area


Adjusts the resolution at the Display area dialog box.

#### Horizontal

Adjusts the horizontal area displayed by this projector. Decrease or increase value with the Control pad, and then press the SELECT button.

#### Vertical

Adjusts the vertical area displayed by this projector. Decrease or increase value with the Control pad, and then press the SELECT button.



Adjust value with the Control pad.



#### Current mode

Press the SELECT button at the Current mode to show the information of the connected computer.

H-Sync freq.	48.5
V-Sync freq.	60.0
	Quit

#### Position

Adjusts picture position.

#### V-sync phase

Adjust this item when the projected image is affected by the noise from the external equipment. (From 0 to 15)

#### Note:

V-sync phase is not displayed as the item is initially checked off on My menu in the Setting menu. Change the My menu setting in the Setting menu (p51) when necessary to adjust V sync. phase.

#### Reset

Resets all adjustments to their previous levels.

#### Mode

To store the adjustment data or clear the stored data, move the yellow frame pointer to Mode and then press the SELECT button.

#### Store


To store the adjustment data, select Store and press the SELECT button to display Mode dialog box. Move the yellow frame pointer to any of Mode 1 to 50 in which you want to store and then press the SELECT button.

#### Free

To clear the adjustment data previously set, select Free and press the SELECT button to display Mode dialog box. Move the yellow frame pointer to any of Mode 1 to 50 in which you want to clear and then press the SELECT button.

#### Quit

Exits the PC Adjust Menu.



Press the SELECT button at the Display area and the Display area dialog box

#### To store adjustment data

Where to store?		Input	Input 1	
		Source	RGB (PC	Analog)
Mode 1	Free	System	XG	A 1
Mode 2	Free 🕨	Fine sync	1	в
Mode 3	Free >	Total dots	134	4
Mode 4	Free 🕨		Phase	Width
Mode 5	Free >	Clamp	16	0
Mode 6	Free >		Н	V
Mode 7	Free >	Display area	1024	768
Mode 8	Free	Position	H 289	36

Vacant Mode

shows the selected input, source and system, and values of "Fine sync," "Total dots," "Clamp," "Display area," and "Position."

To clear adjustment data

Where	to free?		Input	Inp	ut 1
			Source	RGB (PC	Analog)
Mode 1	Stored		System	XG	A 1
Mode 2	Free		Fine sync	1:	8
Mode 3	Free		Total dots	134	14
Mode 4	Free			Phase	Width
Mode 5	Free	Þ	Clamp	16	0
Mode 6	Free			H	V
Mode 7	Free		Display area	1024 H	768 V
Mode 8	Free		Position	289	36
	•				

#### ✔Note:

Fine sync. and Display area cannot be selected when "480i", "575i", "480p", "575p", "720p", "1035i", or "1080i" is selected in the System menu (p40).




Image

selects image level from Standard, Cinema, Real, and Image 1~10.

- Press the MENU button to display On-Screen Menu. Spin 1 the menu icons with the Control pad and press the SELECT button when the IMAGE icon comes right in front.
- Move the yellow frame pointer with the Control pad to an 2 image level which you want to select and then press the SELECT button.

#### Image Menu (PC)



Move the yellow frame pointer to an image level you want to select and then press

Indicates the other items exists below.

#### **IMAGE 1~10**

**For PC Input** 

Standard

Real

User preset picture adjustment in IMAGE ADJ. menu (p45~47).

Normal picture level preset on this projector for PC mode.

Picture level with improved halftone for graphics.

#### For AV Input

#### Standard

Normal picture level preset on this projector for AV mode.


#### Cinema

Picture level adjusted for picture with fine tone.

#### **IMAGE 1~10**

User preset picture adjustment in IMAGE ADJ. menu (p45~ 47).

#### Image Menu (AV)



Note:

Image 1~10 are common for PC and AV sources, which means 10 memory areas are prepared for PC and AV sources totally.



## Image Adjust

adjusts Contrast, Brightness, Color, Tint, Color management, Auto picture control, Color temp., Red, Green, Blue, Sharpness, Gamma, Noise reduction, Progressive, Film, and selects Reset and Store.

- Press the MENU button to display On-Screen Menu. Spin the menu icons with the Control pad and press the SELECT button when the IMAGE ADJ. icon comes right in front.
- 2 Move the yellow frame pointer with the Control pad to an item which you want to adjust.
- **3** Press the SELECT button to display an adjustment dialog box. Adjust value with the Control pad.

#### Contrast

Decrease or increase contrast with the Control pad. (From 0 to 63.)

#### Brightness

Adjust image darker or brighter with the Control pad. (From 0 to 63.)

#### Color

Lighten or deeper color with the Control pad. (From 0 to 63.)

#### Tint

Adjust with the Control pad to obtain proper color. (From 0 to 63.)

#### **Color management**

The Color management function enables you to adjust color level, phase and gamma of the selected spot of the projected image and exchange the original color with the adjusted one. The projector can store up to eight color management data.

#### **Color selection**


Press the SELECT button when Color management is highlighted and then Color management pointer will appear. Move the pointer to a spot which you want to adjust the color of with the Control pad, and press the SELECT button. The image being projected freezes and Color Selection window will appear.

X-axis of COLOR pallet shows Phase and Y-axis, Level. Select a level and phase which you prefer with the Control pad and press the SELECT button to move the pointer to GAMMA. Select a position of GAMMA which you prefer with the Control pad and press the SELECT button.


While adjusting COLOR and GAMMA, the projected image color will change accordingly.

#### ✔ Note:


- Color and Tint cannot be displayed when PC input source is selected.
- Tint cannot be adjusted when the video system is PAL, SECAM, PAL-M or PAL-N. (p40)



#### **Color selection**



Move the pointer to a spot which you want to adjust the color of and then press the SELECT button. Color Selection window will appear as below.



Move the pointer to one of the followings with the Control pad and press the SELECT button.

- LIST.....displays Color Management List window to store the adjustment data.
- COLOR.M ..returns to the previous image with the Color management pointer.
- MENU ......displays a confirmation dialog box. Select "Yes" to return to the menu display.

#### **Color management list**

After selecting LIST on the Color selection window, Color Management List will appear. Move the pointer to one of the followings with the Control pad and press the SELECT button.

ALL DEL.....deletes all the data on the list.

- MENU ......displays a confirmation dialog box. Select "Yes" to return to the menu display.
- COLOR M...returns to the previous image with the Color management pointer.

Press the CANCEL button to exit the Color management mode.

#### Auto picture control

With this function enabled, the projected image will be easier to see by emphasizing black of the picture. Select one from the following settings:

- Off .....disabled
- L1 ..... emphasizes black of the picture.
- L2 .....emphasizes black of the picture greater than L1.

#### Color temp.

Select a level among XLow, Low, Mid and High with the Control pad and the SELECT button.

#### Red

Lighten or deepen red tone of the picture with the Control pad. (From 0 to 63.)

#### Green

Lighten or deepen green tone of the picture with the Control pad. (From 0 to 63.)

#### Blue

Lighten or deepen blue tone of the picture with the Control pad. (From 0 to 63.)

#### Note:

If either value of Red, Green, and Blue is adjusted, "Adj." will be selected in Color temp. automatically.

#### Sharpness

Soften or sharpen the image with the Control pad. (From 0 to 31.)

#### **Color management list**




Move the pointer to the selected color and press the SELECT button. The confirmation dialog box appears.




Clear the check mark with the SELECT button not to apply the adjusted color to the projected image.

Select [Yes] to return to the menu display.



The setting selected.



The setting selected.

#### Gamma

Adjust with the Control pad to obtain better balance of contrast. (From 0 to 15.)

#### Noise reduction

Select one of the followings to reduce noise of the image.

- Off ....disabled
- L1 .....Select "L1" for an active picture.
- L2 . . . . .Select "L2" for a still picture.

#### Progressive

With this function On, interlaced video signal is displayed in a progressive picture.

#### Film

This function is effective on 2:3 or 2:2 pulldown video sources. With this function On, the projector reproduces pictures faithful to the original film quality.

#### Store

To store the adjustment data, move an yellow frame pointer to Store and press the SELECT button. Image Level Menu will appear. Move the yellow frame pointer to one of Image 1~10 and then press the SELECT button.

#### Reset


Reset all adjustments to their previous figures.

#### Quit

Exits Image Adjust menu.

#### Note:

- Progressive, Film, and Noise reduction cannot be displayed when selecting PC input source.
- Progressive cannot be selected when 480p, 575p, and 720p is selected in the System menu. (p40)
- Film can only be activated when selecting PAL, NTSC, 480i or 575i for Video System and "On" for Progressive.
- 2:3 Pulldown or Telecine transfer is the process of changing images from film mode to video mode. While film runs at 24 frames per second (fps), NTSC television signals (or video) have a run rate of 30fps so the 24 fps film needs to be speeded up to 30fps and transferred using a proper field pattern to get the best film-like images. 2:2 Pulldown uses the same process of changing images as 2:3 pulldown, but the difference is that 24 fps film is speeded up for PAL television signal (or video) having 25 fps.






Image 1	
Image 2	ok,
Image 3	
Image 4	
Image 5	
Image 6	Image Move
Image 7	image
Image 8	buttor
Image 9	appea

Image 10

mage Level Menu

No

Move the yellow frame pointer to an image and then press the SELECT button. The confirmation box appears. Select [Yes] to store the image

adjusted.

### **Screen Setting**



Screen Setting

selects the screen size from Normal, Wide, True and Full screen; customizes it by Scale, H&V, Position, Common and Reset; adjusts it by Digital zoom +/–, Keystone and sets Ceiling and Rear.

- Press the MENU button to display On-Screen Menu. Spin the menu icons with the Control pad and press the SELECT button when the SCREEN SETTING icon comes right in front.
- 2 Move the yellow frame pointer with the Control pad to an item which you want to select.

#### Screen

#### Normal

Provides image to fit screen size.

#### Wide

Provides image to fit wide video aspect ratio (16 : 9) by expanding image width uniformly. This function can be used for providing a squeezed video signal at 16 : 9.

#### True

Provides image in its original size. When the original image size is larger than the screen size, this projector enters "Digital zoom +/-" mode automatically. While "True" is displayed on screen, pan the image with the Control pad. Digital zoom + and - mode can be switched by pressing the SELECT button.

#### Full screen

Provides image to fit the horizontal size of the screen size. When the input signal is SXGA (5:4), the image is fully displayed at 4:3 aspect ratio.

#### Custom (Aspect)


Adjusts aspect (scale and position) of the screen. Press the SELECT button at "Custom". "Custom" will be displayed on the top left of the screen for 4 seconds and then return to the previous menu display. Press the SELECT button again with the pointer staying on Custom to display Aspect setting menu. Adjust each value of Scale and Position.

- Scale  $\ldots$  .adjusts horizontal and vertical scale of the screen. (From –32 to +32)
- H&V ......changes Vertical value subject to Horizontal value; when a checkmark is put on H&V, Scale V cannot be adjusted.
- Position . . . adjusts horizontal and vertical position of the screen. (From –15 to +15)
- Common . .applies the current Aspect setting to all the Inputs.
- Reset .... resets all adjusted values to zero.
- Quit .....exits the Aspect setting menu.


#### Note:

The adjusted aspect can basically be memorized for each input even if the projector is turned off.


#### Screen Setting Menu




#### Screen (Custom)



#### Screen (Custom: H&V)



#### Screen (Custom: Common)



Move the pointer to "Common" and press the SELECT button. The confirmation box appears. Select [Yes] to activate it.

#### D. Zoom

#### D. Zoom +

Press the SELECT button at the D. Zoom +. The message "D. Zoom +" is displayed. Press the SELECT button to expand the image size. And use the Control pad to pan the image. The Panning function can work only when the image is larger than the screen size.

#### D. Zoom –

Press the SELECT button at the D. Zoom –. The message "D. Zoom –" is displayed. Press the SELECT button to compress the image size.

#### Note:

- To exit the D. Zoom +/– mode, try the followings:
- To return to the normal screen, change Input, or change the screen size.
- To exit the panning mode, press any button except the D. ZOOM button, the SELECT button, and the CH and ID buttons.

#### Keystone

This function corrects distortion of a projected image. Press the SELECT button at Keystone twice and The keystone dialog box appears. Adjust keystone with the Control pad.

Press the SELECT button at Keystone and select either Store or Reset with the Control pad, and then press the SELECT button to fix the selection.

- Store . . . .stores the keystone adjustment even if the AC power cord is disconnected.
- Reset ..... resets the keystone adjustment when the AC power cord is disconnected.

#### Ceiling

When this function is "On," the picture is top/bottom and left/right reversed. This function is used to project the image from a ceiling mounting the projector.


#### Rear

When this function is "On," the picture is left/right reversed. This function is used to project the image to a rear projection screen.


#### Note:


- This Screen Menu cannot be operated when "720p(HDTV)", "1035i (HDTV)", or "1080i (HDTV)" is selected in the System Menu (p39~40).
- The True and D. Zoom +/– cannot be selected when projecting AV sources or selecting "480i", "575i", "480p", or "575p" in the System menu (p39~40).
- This projector cannot display any resolution higher than 1600 × 1200. If your computer's screen resolution is higher than 1600 × 1200, reset the resolution to the lower before connecting the source to the projector.
- The image data in other than XGA is modified to fit the screen size in initial mode.
- The panning function may not operate properly if the computer system prepared in the PC Adjust Menu is used.

#### D. Zoom










Rear



### Sound



- Press the MENU button to display On-Screen Menu. Spin the menu icons with the Control pad and press the SELECT button when the SOUND icon comes right in front.
- 2 Move the yellow frame pointer with the Control pad to an item which you want to adjust.
- **3** Press the SELECT button to display an adjustment dialog box. Adjust value with the Control pad.

#### Sound Menu



Sound icon

#### Pointer

(yellow frame) Softly tap the Control pad or grind your finger on the Control pad to move the pointer.



**Item data** Adjust value with the Control pad.

#### Volume

Adjust Volume with the Control pad.

#### Treble

Adjust Treble sound with the Control pad.

#### Bass


Adjust Bass sound with the Control pad.

#### Mute

Select On to cut off sound, and select Off to restore sound.

#### Quit

Exits Sound menu.



### Setting




Setting

changes various settings: Language, Menu, Logo, Background, Lamp, Remote control, Display, Input search, Power management, On start, Analog out, Lens memory, Shutter, Security, and Factory default.

- Press the MENU button to display On-Screen Menu. Spin 1 the menu icons with the Control pad and press the SELECT button when the SETTING icon comes right in front.
- Move the yellow frame pointer with the Control pad to an 2 item which you want to set and then press the SELECT button. The Setting dialog box appears.

#### Setting Menu (Language)



#### Language

The language used in the On-Screen Menu is available in English, German, French, Italian, Spanish, Portuguese, Dutch, Swedish, Russian, Chinese, Korean, or Japanese.

#### Menu

This feature allows you to change the On-Screen Menu setting.

#### Position

When Position is selected, arrows appear in upward, downward, right and left directions on the screen. Move the menu position with the Control pad and fix it by pressing the SELECT button.

#### My menu

This feature enables you to customize the On-Screen menu display. Put checkmarks on items of each menu that you want to display.


#### Simple menu

- On ......When adjusting value in the Image adjust menu, the value adjustment bar is displayed on the bottom left of the screen.
- Off .....Default setting.


#### Note:

- Input and Menu items cannot be hid with the My menu setting.
- When selecting Default on My menu setting, all items of the On-Screen Menu will be displayed.

#### **Menu Position**



#### My Menu



#### Logo

Logo settings can be altered as follows:

#### Logo select

This function decides what to be displayed on the starting-up display as follows:

Default .... the factory-set logo

My logo ... the image you captured

Off .....count-down only

#### Capture

This function enables you to capture the image being projected and use it for a starting-up display or interval of presentations. After capturing the projected image, go to the Logo function and set it to "My logo". Then the captured image can be displayed when turning on the projector next time. (p28)

To capture the image, select [Yes]. To cancel the Capture function, select [No].

#### Note:

- Before capturing an image, select Standard in the Image Menu to capture a proper image. (See page 44.)
- A signal from a computer can be captured up to XGA(1024 x 768). A signal from video equipment can be captured except for 720p, 1035i, and 1080i.
- When capturing the image that has been adjusted by the Keystone function, the adjustment data is automatically reset and the projector captures an image without keystone correction.
- When the Logo lock function is On, the Logo and Capture menu cannot be selected

#### Lock

This function prevents an unauthorized person from changing the Loao settina.

- Off .... the Logo setting can be changed freely from the Logo menu.
- On . . . . . . the Logo setting cannot be changed without PIN code.

If you want to change the Logo Lock setting, enter a PIN code along the following steps. The initial PIN code for Logo Lock setting is set "4321" at the factory.

#### Enter a Logo PIN code

Select a number with the Control pad and fix the number with the SELECT button. The number will change to "\*". If you fixed a wrong number, move the pointer to "C" with the Control pad, then enter the correct number again.


Repeat this step to complete entering a four-digit number.


When the four-digit number is fixed, move the pointer to "Ent". Press the SELECT button so that you can change the Logo Lock setting.

If you entered a wrong Logo PIN code, "Logo PIN code" and the number (\*\*\*\*) will turn red and disappear. Enter a correct Logo PIN code all over again.

#### Logo Select

Capture









Select [Yes] to stop capturing.

#### Logo Lock Setting



#### Enter a Logo PIN code



The input numbers change to "\*" for security.

Logo	PIN c	ode?
7	8	9
4	5	6
1	2	3
	С	Ent

# Setting

#### **PIN Code Change**

Logo PIN code can be changed to your desired four-digit number. Select "PIN code change" with the Control pad and press the SELECT button. Set a new Logo PIN code.

Be sure to note the new Logo PIN code and keep it at hand. If you lost the number, you could no longer change the Logo PIN code setting. For details on PIN code setting, refer to relevant instructions of the PJ Lock function on page 57.

#### Background

3 background settings are available in this projector. Select one of the followings when no input source is connected to the projector or no input signal is coming from the connected equipment:

Blue .....blue colored background

My logo ... the image you captured

Black .....black colored background

#### Lamp

#### Control

This feature allows you to change brightness of the screen.

Normal . .normal brightness

Auto .... brightness according with the input signal

Eco ....lower brightness reduces the lamp power consumption and extends the lamp life.

#### ✔ Note:

When using 100 W (optional) lamps, the Lamp control setting cannot be altered.

#### Mode

This projector is equipped with two lamps. Mode setting allows you to switch using 1 lamp or 2 lamps.

2-lamp ....lights both of the lamps inside the projector.

1-lamp . . .lights a lamp only. Auto, Lamp1, or Lamp2 can be altered.

#### Note:

- When neither of the two lamps is lighted, the projector will shutdown automatically.
- When either of the two lamps does not light up, the LAMP 1/2 REPLACE indicator is blinking red and the projector will light the other automatically.

#### Remote control

Four remote control channels and eight remote control ID are prepared for the projector to prevent radio frequency interference from the other equipment and mutual interference between projectors when using them at the same time.


For example, operating the projector in "CH-2 and ID-7," both the projector and the remote control must be switched to "CH-2 and ID-7."


#### To change CH and ID for the projector;

Select a remote control CH and ID in this Setting menu. To change CH and ID for the remote control;


While holding down the CH or ID button, press the SELECT button. The remote control CH or ID switches sequentially for one pressing the SELECT button. Changing CH and ID should be done separately. (See page 16 and 17 for details.)

#### PIN Code change Dialog Box






#### Lamp Mode



Lamp 2

When selecting Auto in 1-Lamp mode, the projector automatically selects either lamp of which the total Lamp time is shorter and lights it up.

#### **Remote control**



When pressing the SELECT button at Remote control, the remote control CH and ID menu appears. Select CH and ID respectively.

#### Display

This function decides whether to display On-Screen Displays.

On ....shows all the On-Screen Displays.

Off .....sets On-Screen Displays disappeared except;

- On-Screen Menu
- "Power off?" message
- P-TIMER
- "No signal" message
- "Please wait.." message
- "Searching.." message

#### Input search

With this function On, the projector automatically starts input signal search from Input 1 to Input 5 when turning on the projector. This automatic search stops at the Input where the projector detects any input signal connected.

#### Note:

When the last selected input source in the Input menu differs from the detected input source, the projector may not display the image properly.

#### Power management

For reducing power consumption as well as maintaining the lamp life, the Power Management function starts the count down when the input signal is interrupted and no button is pressed for 30 seconds or more.

If the input signal is interrupted and no button is pressed for 30 seconds or more, the timer display with the message "No signal" appears on the screen. The count-down of the set time will get started. The count-down time can be set between 1 and 60 minutes.

When the count-down time has been elapsed, the lamp will be turned off to cool itself down. The POWER indicator is lighting red during this cooling-off period. The next operation depends on the setting as follows :

- Ready ..... When the lamp has been fully cooled down, the READY indicator changes to green blinking. In this condition, the projection lamp will be turned on if the input signal is reconnected or any button on the top control or remote control unit is pressed.
- Shut down . . .When the lamp has been fully cooled down, the power will be turned off.
- Off .....The Power Management function is canceled.

#### On start

When this function is "On," the projector is automatically turned on just by connecting the AC power cord to a wall outlet.


#### Note:

Be sure to turn the projector off properly (see "Turning Off the Projector" on page 29). If the projector is turned off in the wrong steps, the On start function does not operate properly.


#### **Power management**




Time left until Lamp off



Press the SELECT button at Power management and this box appears. Choose "Off" to disable the timer setting, "Ready" or "Shutdown" to enable the timer setting.





**Timer Setting** 

Move the pointer to the timer and set time with the Control pad and press the SELECT button. The timer window disappears and then choose "Ready" or "Shutdown" to enable the timer setting.

Setting

#### Analog out

The ANALOG OUT terminal is for output of the analog signal coming from the ANALOG IN terminal in the Input 1 terminals. (See page12.)

Select "On" to enable the signal output through the ANALOG OUT terminal always except in the stand-by mode or "Off" to disable the signal output.

Analog out is not available when selecting the other Inputs except Input 1. Select Input 1 so that Analog out will be available. (p31, 37)

#### Lens memory

Lens memory feature enables you to store the lens shift, zoom and focus adjustment for each Input. When selecting Lens memory, Input 1~5 will be displayed. Move the pointer to an Input and press the SELECT button. Choose one of the following settings for the Input.

Off..... applies the lens shift, zoom and focus adjusted last.

Memory . . . . stores the lens shift, zoom and focus currently adjusted for each input. When switching to the input with "Memory" selected, the lens moves to the stored position.

#### Note:

- Lens memory is available only in the lens having memory functions of itself. Contact the sales dealer or the service station for available lens.
- 100% accurate lens memory is not guranteed. If an accurate lens position, zoom and focus cannot be obtained with Lens memory function, adjust them respectively.

#### Shutter

Shutter function is available to block out light to the screen, so that the screen can be used for the other presenters. Moreover, this function enhances the effectiveness of contrast by 80% opening up the shutter inside the projector.

Each setting for the Shutter function can be altered as follows:

#### Level

Sets up shutter level when releasing the mechanical shutter.

High contrast .....20% light blocking

#### Protection

Prohibits the shutter operation from the remote control and the projector's top control.

Remote control	Selecting "On" prohibits the shutter operation
	from the remote control.
Projector	Solacting "On" prohibits the shutter operation


Projector ...... Selecting "On" prohibits the shutter operation from the top control.

It is possible to prohibit the shutter operation from both of the remote control and the top control.


#### Lens memory




Press the SELECT button at Lens memory and choose an Input for which you want to store the lens shift, zoom and focus adjustment and then select "Memory" for the input.



#### Shutter level



#### **Shutter protection**



When pressing the SELECT button at Shutter, the Shutter setting menu appears. Select Protection and then a desired setting for Remote control and Projector.

#### Shutter Management

The Shutter Management function turns off the projection lamp when the projector is left with the shutter released and the set time has passed away. The count-down time can be set between 5 and 180 minutes.

When the count-down time has elapsed, the shutter will be opened up automatically and the lamp will be turned off to cool itself down. The SHUTTER indicator is blinking blue during this cooling-off period. When the lamp has been fully cooled down, the READY indicator turns green lighting and the SHUTTER indicator keeps blinking. Should the POWER button be pressed in this condition, the projection lamp will be turned on and the SHUTTER indicator turns off.

#### Note:

While the Shutter is released, timer setting of the Power management is invalid.

#### Security

#### **Key lock**

This function locks operation from the top control and remote control. It is useful to prevent the projector from being operated by an unauthorized person.

- Projector ......locks operation from the top control. To unlock, use the remote control.
- Remote control ...locks operation from the remote control. To unlock, use the top control.
- Off ..... does not lock any operation. To release lock, select this.

If the top control accidentally becomes locked and you do not have the remote control nearby, disconnect the AC power cord from the AC outlet, and then with pressing the SELECT button, reinsert the AC power cord. This will cancel the top control lock.

#### USB lock

This function prevents the projector from being operated by an unauthorized person with the optional USB key and provides the following settings for security options.

Setting ..... key lock setting (On1, On2, and Off)

Registration . .registers 2nd USB key into the projector. (First key can be registered by just being connected to the projector in turning on.)


Delete .....deletes the registered USB keys.

To set the USB lock, the optional USB key is required. Refer to p75 for the optional USB key and contact the sales dealer for purchasing. Refer to the owner's manual enclosed with the USB key for detail operation of the USB lock.


#### Note:

- USB lock cannot be selected when the optional USB key is not connected to the projector. (p13)
- When either of USB lock or PJ lock is set, the other cannot be selected.
- USB key function can be used only with our specified optional USB key. We do not guarantee operation with the other USB keys commarcially supplied.

#### **Shutter Management**




Select Management and set the timer between 5 and 180 minutes.



The setting selected.





Setting

#### PJ lock

This function prevents the projector from being operated by an unauthorized person and provides the following settings for security options.

- On1 ..... requires to enter the PIN code every time turning on the projector.
- On2 ....requires to enter the PIN code to operate the projector once the power cord is disconnected; as long as the AC power cord is connected, the projector can be operated without the PIN code.
- Off .... the projector is unlocked with the PIN code. To release PJ lock, select this setting.

Whenever to change the PIN code (the four-digit number), you are required to enter the PIN code. "1234" is set as the initial PIN code at the factory.

#### Enter a PJ PIN code

Select a number with using the Control pad and fix the number with the SELECT button. The number will change to "\*". If you fixed a wrong number, move the pointer to "C" once with the Control pad to clear the number. Enter the correct number again.

Repeat this step to complete entering a four-digit number.

When the four-digit number is fixed, move to "Ent". Press the SELECT button so that you can change the following PIN code lock settings.

If you entered a wrong PIN code, the number (\*\*\*\*\*) will turn red and disappear. Enter a correct PIN code all over again.

#### To Change the PJ PIN Code setting

Select Off, On1, or On2 with the Control pad and then press the SELECT button.

#### To Change PJ PIN Code

The PIN code can be changed to your desired four-digit number.

Select "PJ PIN code change" with the Control pad, and press the SELECT button. The PIN code input dialog box will appear. Enter a current PIN code, and then a new PIN code as follows:

Select a number with the Control pad and fix the number with the SELECT button. Repeat it to complete entering a four-digit number. When the four-digit number is fixed, move the pointer to "Ent". Then press the SELECT button.

#### CAUTION:


WHEN YOU HAVE CHANGED PIN CODE, WRITE DOWN THE NEW PIN CODE IN COLUMN OF THE PIN CODE NO. MEMO ON PAGE 81, AND KEEP IT SECURELY. SHOULD THE PIN CODE BE LOST OR FORGOTTEN, THE PROJECTOR CAN NO LONGER BE OPERATED.

#### PJ lock




When the projector is locked with the PIN code, the PJ lock mark appears at top left of the Main menu.

#### Enter a PIN code



#### Change the PJ Lock setting



#### **Change the PIN code**

Pointer



Select PJ PIN code change and press the SELECT button. The PIN code input dialog box will appear.

The setting selected.



#### Factory default

This function returns all setting values to the factory default settings except for those including: User logo, PJ PIN code, Logo PIN code, Security setting, Lamp time, Filter time and PJ time.

#### Quit

Exits the Setting menu.

#### Factory default



Select Factory default and this box appears. Select [Yes], and the next box appears.

Return to Factory default?			
Yes			
No			



Select [Yes] to activate it.

### Special



Special

customizes control functions: Lamp, Fan control, Filter, Auto PC adj., Test pattern, RS-232C, and USB memory and displays Warning log.

- Press the MENU button to display On-Screen Menu. Spin the menu icons with the Control pad and press the SELECT button when the SPECIAL icon comes right in front.
- 2 Move the yellow frame pointer with the Control pad to an item which you want to select and then press the SELECT button. The corresponding dialog box for the item appears.

This feature displays total time of the lamps being used. Select


To reset the Lamp time, move the pointer to "Reset" and then

press the SELECT button. The message "Lamp time reset?" is


displayed. Move the pointer to [Yes] and then press the SELECT

Lamp 1 or Lamp 2 to show each lamp wattage and time.

#### **Special Menu (Lamp)**



Move the pointer to Reset and then press the SELECT button. The message "Lamp time reset?" is displayed. Select [Yes] and the confirmation box appears.



Select [Yes] to activate it.

### Note:

button.

Lamp

Be sure to reset the Lamp time only after replacing the lamp.

#### Fan control

This function provides you the following alternatives for the cooling fans operation of the projector and the Option box (Smoke Resist Box ) separately provided. See page 75 for the Option box.

Normal ....normal operation Max ......faster operation than "Normal".

Select "Normal" for usual operation and "Max" to enhance the cooling effect.

#### Note:

Setting of the cooling fans of the projector and the option box cannot be changed independently.

#### Filter

This feature displays total time of the filter on the projector and the Option box (Smoke Resist Box) being used.

To reset the Filter time, move the pointer to "Reset" and then press the SELECT button. A confirmation box appears. Move the pointer to [Yes] and then press the SELECT button.

#### Note:

Option box cannot be selected when it is not mounted on the projector. For the information of the Smoke Resist Box, refer to Optional Parts on p75 and contact the sales dealer or the service station.


#### Fan control



Select Fan control and this box appears. Select one of these settings with the Control pad and press the SELECT button to enable it.

Normal	
Max	

The setting selected.



Select [Yes] to activate it.

#### Auto PC adj.

Select "On" to enable the Auto PC adjust function and "Off" to disable it. Refer to page 31 and 41 for Auto PC adjust function.

#### Test pattern

Various test patterns are prepared in this projector allowing users to test the projection. Select one from the following twenty kinds of patterns: Cross 1 (W), Cross 2 (R), Cross 3 (G), Cross 4 (B), Cross 5 (M), Cross 6 (C), Cross 7 (Y), Gradation 1~4, Color, and Flat 1~8.

To cancel the Test pattern, press the CANCEL button on the top control or the remote control.

#### RS-232C

This feature allows users to set serial communication configuration (baud rate and the projector ID) when connecting several projectors via the RS-232C terminal of the projector. (p13, 80)

- Projector ID ...001 ~ 999 \*
- Default . . . . . returns Baud rate and Projector ID to factory default setting

(Baudrate: 19200, Projector ID: 001)

\* Under 100, Projector ID is displayed as 1~99.

#### USB memory

This feature allows users to store PC mode and Image adjustment data on the optional USB key connected to the projector and recall it from the USB key. PC mode data and Image adjustment data can be stored separately on respective 10 memory areas of the USB key. (PC mode data: mode 1–50 x 10, Image adjustment data: Image 1-10 x 10) (p43, 47)

- Save ......stores the adjustment data on the USB key connected to the projector.
- Load .....recalls the stored data.
- Delete ......deletes the stored data.


To use the USB memory function, the optional USB key (separately provided) is required. Refer to p75 for the USB key information and contact the sales dealer or service station for purchasing. Refer to the owner's manual enclosed with the USB key for further information on USB memory function.

#### Note:


60

- USB memory function cannot be operated without our specified optional USB key. See page 75 for the optional parts.
- USB memory cannot be displayed without the optional USB key connected to the projector. (p13)

#### Test pattern




Select Test pattern and then the Test pattern selection box is displayed. Choose one of these patterns with the Control pad and press the SELECT button to display the selected pattern on screen.




Indicates the other items exist below.





The item selected.





To be continued to the next page.

Special

#### Warning log


Warning log shows the information of the past warning history of the projector. Up to 50 logs can be displayed. Log contents are as follows:

Lamp-1 failure Lamp-2 failure Lamp-2 timeover Power failure Inside temp. A error Inside temp. B error Inside temp. C error External temp. error Power off (Power management) Power off (Shutter management) PJ filter timeover Option box filter timeover Option box error

#### Quit

2

Exits Warning log menu.




USB Memory Menu

Move the yellow frame pointer to a USB memory to store the data and then press the SELECT button. The confirmation box appears.



Select [Yes] to activate it.

#### Warning log



Exits the Warning log menu.



control and the remote control.

displays current setting information: Input, System, Signal, Screen, Language, Lamp mode, Lamp status, Power management, Shutter management, Smoke resist, Option filter time, Security, and Remote control.

Press the MENU button to display On-Screen Menu. Spin the menu icons with the Control pad and press the SELECT button when the INFORMATION icon comes right in front.

The Information window appears. The information window

can be displayed by pressing the INFO button on the top

#### pin **Information** CT

Input	Input 1		
	RGB (PC Analog)		
System	VG	A 1	
Signal	Y	es	
Screen	Nor	rmal	
Language	Eng	glish	
Lamp mode	2- Lamp		
Lamp status	Lamp 1	Normal	
	Lamp 2	Normal	
Power management	Off		
Shutter management	On 180 Min.		
Smoke resist	Yes		
Option filter time	0	Hour(s)	
Security	Key lock Of		
	PJ lock	Off	
	USB lock	Off	
Remote control	CH-1	ID-1	
Option Control No. 05		Quit	

### Warning Temp Indicator

The WARNING TEMP indicator shows the state of the function which protects the projector. Check the state of the WARNING TEMP indicator and the READY indicator to take proper maintenance.

#### <u>The projector is shut down and WARNING TEMP indicator is</u> <u>blinking red.</u>

The WARNING TEMP indicator slowly blinks red to let you know the internal temperature of the projector exceeds the normal level. If the temperature goes up further, the WARNING TEMP indicator turns fast blinking and then the projector will be turned off automatically. Then, the READY indicator will go out, but the WARNING TEMP indicator keeps blinking red. When the temperature inside the projector returns to normal, the READY indicator lights green and then the projector can be turned on. If the WARNING TEMP indicator still keeps blinking after the projector is turned on, check the followings;

#### Note:

Even after the temperature inside the projector returns to normal, the WARNING TEMP indicator continues to blink and does not go out until the projector is turned on again.

#### Then check the matters below:

- Did you provide appropriate space for the projector to be ventilated? Check the installing condition to see if ventilation slots are not blocked.
- Is the projector not installed near the ventilation duct of airconditioning equipment which may be hot? Install the projector away from the ventilation duct of air-conditioning equipment.
- Are the air filter clean? Check the air filter periodically. (p63)

If the WARNING TEMP indicator remains blinking after performing above checks, the cooling fans or the internal circuits may be malfunctioned. Contact the service station for check and repair.

#### All indicators except the LAMP indicator are blinking3.


When the projector detects an abnormal condition, it is automatically shut down to protect the inside and all the Indicators except the LAMP indicator start blinking. In this case, disconnect the AC power cord and reconnect it, and then turn the projector on once again for check. If the projector cannot be turned on, disconnect the AC power cord and contact service station for check and repair.




#### CAUTION

DO NOT LEAVE THE PROJECTOR WITH THE AC POWER CORD CONNECTED UNDER THE ABNORMAL CONDITION. IT MAY RESULT IN FIRE OR ELECTRIC SHOCK.

#### **TOP CONTROL**



#### **TOP CONTROL**



### Air Filter Replacement

Air filters prevent dust from accumulating on the surface of the optical elements inside the projector. Should the air filters become clogged with dust particles, it will reduce cooling fans' effectiveness and may result in internal heat build up and adversely affect the life of the projector. Proper maintenance should be taken.

#### WARNING FILTER Indicator

This projector can monitor the filter condition. When the filter is clogged with dust and the performance is degraded, the WARNING FILTER indicator lights orange and let you know the filter replacement is required.

If the indicator is lighting orange, turn off the projector and replace the air filter immediately.

Using the projector with the WARNING FILTER indicator lighting may result in internal heat build up and cause damage to the optical elements inside the projector. The projector will shutdown automatically to protect itself when the projector's inside temperature is abnormally high.

- Turn off the projector, and disconnect the AC power cord 1 from the AC outlet.
- Pulling down the tabs on both sides top of the filter cover, 2 open the projector cover.
- 3 Pull out the air filter from the projector.
- Replace the new air filter and the filter cover properly onto 1 the projector.
- Reset the Filter time. See "Filter" in the Special menu on 5 p59.

#### CAUTION

Do not operate a projector with Air Filter removed. Dust may accumulate on LCD Panel and Mirror degrading picture quality.


Do not put small parts into Air Intake Vents. It may result in malfunction of a projector.

#### RECOMMENDATION

#### We recommend avoiding dusty/smoky environments when operating a projector. Usage in these environments may cause poor image quality.

When using under dusty or smoky conditions, dust may accumulate on liquid crystal panel, lens, or optical elements inside it. This condition may degrade quality of projected image. When above symptoms are noticed, contact your authorized dealer or service station for proper cleaning.

#### **TOP CONTROL**



- The projector cannot be operated with the air filter removed; it will shut down automatically if the air filter is removed while the projector is operating.
- Used in a place where the air pressure is relatively low such as highlands, the WARNING FILTER indicator may light orange even the air filter is clean.

### ORDER REPLACEMENT FILTER

When ordering the replacement air filter, give the following information to the dealer.

- Model No. of your projector ÷
  - LC-X6
- **Replacement Filter Parts No.** : 610 315 1588


### Lamp Replacement

When the life of the projection lamp of this projector draws to an end, the LAMP1 and 2 REPLACE indicators light orange. If this indicator lights orange, replace the lamp with a new one promptly.

# 

For continued safety, replace with a lamp of the same type. Do not drop a lamp or touch a glass bulb! The glass can shatter and may cause injury.

Allow a projector to cool, for at least 45 minutes before you open the Lamp cover. The inside of the projector can become very hot.



These indicators light orange when the life of the projection lamps draws to an end.


Follow these steps to replace the lamp.

- *I* Turn off the projector and disconnect the AC plug. Allow the projector to cool for at least 45 minutes.
- 2 Loosen each screws on the lamp covers with a screwdriver, and remove the lamp covers.
- **3** Loosen 2 screws of each lamp with a screwdriver and pull out one lamp and another with grasping the handle.
- **4** Replace the lamp with a new one and tighten the 2 screws back into the positions. Make sure that the lamp is set properly. Replace the lamp covers and tighten the screws.
- 5 Connect the AC power cord to the projector and turn on the projector.
- 6 Reset the Lamp time. See "Lamp time" on p59.

#### **CAUTION**:

DO NOT OPERATE A PROJECTOR WHILE ANY OF LAMPS IS REMOVED. IT MAY RESULT IN MALFUNCTIONS, FIRE HAZARD, OR OTHER ACCIDENTS.





Handle

#### ORDER REPLACEMENT LAMP

Replacement Lamp can be ordered through your dealer. When ordering a Projection Lamp, give the following information to the dealer.

5

2

- Model No. of your projector
- LC-X6
- Replacement Lamp Type No.
- POA-LMP80

(Service Parts No. 610 315 7689)

# <u>А</u> L

# LAMP HANDLING PRECAUTIONS

This projector uses a high-pressure lamp which must be handled carefully and properly. Improper handling may result in accidents, injury, or create a fire hazard.

- Lamp lifetime may differ from lamp to lamp and according to the environment of use. There is no guarantee of the same lifetime for each lamp. Some lamps may fail or terminate their lifetime in a shorter period of time than other similar lamps.
- If the projector indicates that the lamp should be replaced, i.e., if the LAMP REPLACE INDICATOR lights up, replace the lamp with a new one IMMEDIATELY after the projector has cooled down.
   (Follow carefully the instructions in the LAMP REPLACEMENT section of this manual.) Continuous use of the lamp with the LAMP REPLACE INDICATOR lighted may increase the risk of lamp explosion.
- A Lamp may explode as a result of vibration, shock or degradation as a result of hours of use as its lifetime draws to an end. Risk of explosion may differ according to the environment or conditions in which the projector and lamp are being used.


#### IF A LAMP EXPLODES, THE FOLLOWING SAFETY PRECAUTIONS SHOULD BE TAKEN.

If a lamp explodes, disconnect the projector's AC plug from the AC outlet immediately. Contact an authorized service station for a checkup of the unit and replacement of the lamp. Additionally, check carefully to ensure that there are no broken shards or pieces of glass around the projector or coming out from the cooling air circulation holes. Any broken shards found should be cleaned up carefully. No one should check the inside of the projector except those who are authorized trained technicians and who are familiar with projector service. Inappropriate attempts to service the unit by anyone, especially those who are not appropriately trained to do so, may result in an accident or injury caused by pieces of broken glass.

### **Cleaning the Projection Lens**

Follow these steps to clean the projection lens.


- 1 Disconnect the AC power cord before cleaning.
- 2 Softly wipe the projection lens with a cleaning cloth that contains a small amount of non-abrasive camera lens cleaner, or use lens cleaning paper or a commercially available air blower to clean the lens. Avoid using an excessive amount of cleaner. Abrasive cleaners, solvents, or other harsh chemicals might scratch the surface.
- ${f 3}$  When the projector is not in use, replace the lens cover.



### **Cleaning the Projector Cabinet**

Follow these steps to clean the projector cabinet.


- 1 Disconnect the AC power cord before cleaning.
- 2 Softly wipe the projector body with a soft, dry cleaning cloth. When it is heavily soiled, use a small amount of mild detergent and finish with a soft, dry cleaning cloth. Avoid using an excessive amount of cleaner. Abrasive cleaners, solvents, or other harsh chemicals might scratch the surface.
- **3** When the projector is not in use, put the projector in an appropriate carrying case to protect it from dust and scratches.



### Attaching the Cord Cover Strap

When mounting the projector on the ceiling, connect the front cover to the projector with the provided cord cover strap to avoid the front cover from falling down.

- *I* Race the string through a hole on right edge of the projector's terminal area.
- 2 Fix the string to a hole inside the front cover with the screw.



### Indicators and Projector Condition

#### **Main Indicators**

Indicators							
READY Green	WARNING TEMP <b>Red</b>	LAMP <b>Red</b>	Projector Condition				
			The projector is OFF. (The AC power cord is unplugged.)				
		0	The projector is preparing for stand-by or the projection lamp is being cooled down. The projector cannot be turned on until cooling is completed.				
$\bigcirc$	•	$\bigcirc$	The projector is ready to be turned on with the POWER ON-OFF button.				
$\bigcirc$			The projector is operating normally.				
			The projector is in the Power management mode.				
		0	The temperature inside the projector is abnormally high. The projector cannot be turned on. When the projector is cooled down enough and the temperature returns to normal, the LAMP indicator lights red and the projector can be turned on.				
0		$\bigcirc$	The projector has been cooled down enough and the temperature returns to normal. When turning on the projector, the WARNING TEMP indicator stops blinking. Check and clean the air filters.				
TEMP, SHU WARNING F 1 REPLACE REPLACE in	READY, WARNING TEMP, SHUTTER, WARNING FILTER, LAMP 1 REPLACE AND LAMP 2 REPLACE indicators are blinking all together.		The projector detects an abnormal condition and cannot be turned on. Unplug the AC power cord and plug it again to turn on the projector. If the projector is turned off again, disconnect the AC power cord and contact the dealer or the service center for service and checkup. Do not leave the projector on. It may cause electric shock or a fire hazard.				
LED Con	ditions:	••• Off	) • • • Lighting • • • Dim lighting				

#### **Shutter Indicator**

Indicators							
READY Green	LAMP <b>Red</b>	SHUTTER Blue	Projector Condition				
0		0	The shutter is released. (The projector is On.)				
0	0	Slow	In Shutter management mode. (The projector is in the stand-by mode.)				
	0	Slow	In Shutter management mode. (The projector is in the cooling mode.)				
0	0	Fast	The shutter is out of control. (The projector is in the stand-by mode.) In this case, contact the service station immediately.				
	0	Fast	The shutter is out of control. (The projector is in the cooling mode.) In this case, contact the service station immediately.				

#### Warning Filter Indicator

Indicators					
READY Green	LAMP Red	WARNING FILTER <b>Orange</b>	Projector Condition		
0		Slow	The air filter is clogged with dust or has been used overtime.		
0	•	0	The air filter has been used overtime.		
		Fast	The air filter is not installed.		

#### Lamp Replace Indicators

Indicators							
READY Green	LAMP <b>Red</b>	LAMP 1/2 REPLACE Orange	Projector Condition				
	0	Slow	The lamp cannot light up. (The projector is preparing for stand-by or the projection lamp is being cooled down. The projector cannot be turned on until cooling is completed.)				
0	0	Slow	The lamp cannot light up. (The lamp has been cooled down enough and the projector is in stand-by mode and ready to be turned on with the POWER ON-OFF button.)				
	$\bigcirc$	Fast	The lamp is not installed in the projector.				
0		0	The lamp of which indicator is blinking has been used overtime. Replace the lamp and then reset the Lamp time. The indicator will turn off.				
		Both	Either lamp cover is not replaced or fit in. Both of the indicators keeps blinking three times at regular intervals and the projector cannot be turned on.				
0	0	Alternate	One lamp is different from the other in wattage. (For example, installed a lamp on 300W and the other on 100W.) If the POWER button is pressed in this condition, the projector will be turned on with Lamp 1 only and then shut down automatically 1 minute later.				

\*When the LAMP 1 REPLACE indicator and the LAMP 2 REPLACE indicator light orange, replace the projection lamps with new ones promptly. And then reset the Lamp time after replacement of the lamps. See page 59, 64 and 65.

### Troubleshooting

Before calling your dealer or service center for assistance, check the items below once again.

- Make sure you have properly connected the projector to peripheral equipment as described on page 22~25.
- Make sure all equipment is connected to AC outlet and the power is turned on.
- When you operate the projector with a computer and it does not project an image, restart the computer.

See Information by pressing the INFO. button to check the current projector condition before trying the solutions below.

Problem:	- Solutions				
No power	<ul> <li>Plug the power cord of the projector into the AC outlet.</li> <li>Make sure the Main On/Off switch is on.</li> <li>See if the LAMP indicator lights red.</li> <li>Wait 90 seconds after the projector is turned OFF when turning the projector back on. The projector can be turned on after the READY indicator turns green. (** "Turning Off the Projector" on page 29)</li> <li>Check the WARNING TEMP. indicator. If the WARNING TEMP. indicator lights red, the projector cannot be turned on.</li> <li>(** "Warning Temp Indicator" on page 62)</li> <li>Check the projection lamp. (** page 64)</li> <li>Unlock Key lock for the projector in the Setting Menu. (** page 56)</li> <li>Check if the air filter is fully installed and the filter cover is completely closed. (** page 63)</li> <li>Check the wattage of two lamps are the same. (** page 59, 64)</li> </ul>				
Image is out of focus.	<ul> <li>Adjust focus of the projector. (r page 30)</li> <li>Check the projection lens to see if it needs cleaning. (r page 66)</li> <li>Moving the projector from a cool to a warm place may result in moisture condensation on the projection lens. In such cases, leave the projector OFF and wait until condensation disappears.</li> </ul>				
No image	<ul> <li>Check the connection between your computer or video equipment and the projector. (INF page 22–25)</li> <li>See if the input signal is correctly output from your computer. Some laptop computers may need to change the setting for monitor output when connecting to a projector. See your computer's instruction manual for the setting.</li> <li>It takes about 20 seconds to display an image after turning on the projector.</li> <li>See if the selected system is corresponding with your computer or video equipment. (INF page 39–40)</li> <li>Select correct input source once again through menu operation. (INF page 37–38)</li> <li>Make sure the temperature is not out of the specified Operating Temperature (5°C ~ 35°C).</li> <li>Check if the shutter is released. (INF page 30)</li> </ul>				
lmage is dark.	<ul> <li>Adjust Brightness and Contrast in the Image adjust menu. (I page 45)</li> <li>Check the Shutter level. (I page 55)</li> <li>Check each lamp condition and the LAMP 1/2 REPLACE indicators. (I page 64, 69)</li> </ul>				
Image is Left/Right reversed. Image is Top/Bottom reversed.	<ul> <li>Check the Ceiling / Rear item. (ISF "Screen Setting" on page 49.)</li> <li>Check the Ceiling item. (ISF "Screen Setting" on page 49.)</li> </ul>				

No sound	<ul> <li>Check audio cable connection from audio input source.</li> <li>Adjust the audio source.</li> <li>Press the Volume (+) button. (INF page 33)</li> <li>Press the Mute button. (INF page 33)</li> </ul>				
Some displays are not seen during the Operation.	– Check the Display item. (🖙 "Setting" on page 54)				
Only part of image is displayed. (Large/Small)	<ul> <li>Check if you are in D. Zoom+/- mode. (ISP page 33, 49)</li> <li>Change Aspect setting in the Screen setting menu. (ISP page 48)</li> <li>Adjust Display area and Position in the PC adjust menu. (ISP page 42–43)</li> </ul>				
PIN code dialog box appears at start-up.	<ul> <li>PJ PIN code lock is being set. Input a PIN code (1234 or numbers you have set). (IST "Enter a PJ PIN Code" on page 28 and 57)</li> </ul>				
Image is not displayed on the monitor connected to the ANALOG OUT terminal.	<ul> <li>Select Input 1 with the Input button on the top control or the INPUT 1 butto on the remote control, or through the Input Menu. (I page 31 and 37)</li> <li>Make sure Analog out is "On". (I TST "Setting" on page 55)</li> </ul>				
The Top Control does not work.	- Check if the Keylock function is set. (IS "Setting" on page 56)				
The Wireless Remote Control does not work.	<ul> <li>Check the batteries. When replacing, the two batteries should be replaced at the same time. (I page 17)</li> <li>Make sure no obstruction is between the projector and remote control.</li> <li>Make sure you are not too far from the projector when using the remote control. Maximum operating range is 32.8' (10m).</li> <li>Make sure the ID and CH of the remote control is conformed to the projector. (I page 16 and 53)</li> <li>Initialize the remote control ID and CH, and then initialize the remote control ID and CH of the projector as well. (I page 16 and 53)</li> <li>Unlock Key lock for the remote control in the Setting Menu. (I page 26)</li> <li>When all the solutions above fail, try Factory default in the Setting menu. (I page 58)</li> </ul>				
USB mouse does not operate properly.	– Check cable connection of the USB mouse and the projector. (1887 page 26)				
SHUTTER button does not operate.	– Make sure Shutter protection is "Off". (IIIST "Setting" on page 55)				
Lens position moves when Input is switched.	– Check Lens memory for each input. (🖙 "Setting" on page 55)				

Some operating menu items do not appear. - Check the My menu setting. (1887 "Setting" on page 51)

#### WARNING : High voltages are used to operate this projector. Do not attempt to open the cabinet.

If problems still persist after following all operating instructions, contact the dealer where you purchased the projector or the service center. Give the model number and explain about the problem. We will advise you how to obtain service.

### Compatible Computer Specifications

Basically this projector can accept a signal from all computers with V, H-Frequency mentioned below and less than 230 MHz of Dot Clock.

ON-SCREEN DISPLAY	RESOLUTION	H-Freq. (kHz)	V-Freq. (Hz)	ON-SCREEN DISPLAY	RESOLUTION	H-Freq. (kHz)	V-Freq. (Hz)
VGA 1	640 x 480	31.47	59.88	XGA15	1024 x 768	58.03	72.0
VGA 2	720 x 400	31.47	70.09	MAC 19	1024 x 768	60.24	75.08
VGA 3	640 x 400	31.47	70.09	MAC 21	1152 x 870	68.68	75.06
VGA 4	640 x 480	37.86	74.38	SXGA 1	1152 x 864	64.20	70.40
VGA 5	640 x 480	37.86	72.81	SXGA 2	1280 x 1024	62.50	58.60
VGA 6	640 x 480	37.50	75.00	SXGA 3	1280 x 1024	63.90	60.00
VGA 7	640 x 480	43.269	85.00	SXGA 4	1280 x 1024	63.34	59.98
MAC LC13	640 x 480	34.97	66.60	SXGA 5	1280 x 1024	63.74	60.01
MAC 13	640 x 480	35.00	66.67	SXGA 6	1280 x 1024	71.69	67.19
480i	(Interlace)	15.734	60.00	SXGA 7	1280 x 1024	81.13	76.107
575i	(Interlace)	15.625	50.00	SXGA 8	1280 x 1024	63.98	60.02
480p	(Progressive)	31.47	59.88	SXGA 9	1280 x 1024	79.976	75.025
575p	(Progressive)	31.25	50.00	SXGA 10	1280 x 960	60.00	60.00
SVGA 1	800 x 600	35.156	56.25	SXGA 11	1152 x 900	61.20	65.20
SVGA 2	800 x 600	37.88	60.32	SXGA 12	1152 x 900	71.40	75.60
SVGA 3	800 x 600	46.875	75.00	SXGA 13	1280 x 1024 (Interlace)	50.00	86.00
SVGA 4	800 x 600	53.674	85.06	SXGA 14	1280 x 1024 (Interlace)	50.00	94.00
SVGA 5	800 x 600	48.08	72.19	SXGA 15	1280 x 1024	63.37	60.01
SVGA 6	800 x 600	37.90	61.03	SXGA 16	1280 x 1024	76.97	72.00
SVGA 7	800 x 600	34.50	55.38	SXGA 17	1152 x 900	61.85	66.00
SVGA 8	800 x 600	38.00	60.51	SXGA 18	1280 x 1024 (Interlace)	46.43	86.70
SVGA 9	800 x 600	38.60	60.31	SXGA 19	1280 x 1024	63.79	60.18
SVGA 10	800 x 600	32.70	51.09	SXGA 20	1280 x 1024	91.146	85.024
SVGA 11	800 x 600	38.00	60.51	SXGA 21	1400 x 1050	63.90	60.00
MAC 16	832 x 624	49.72	74.55	MAC	1280 x 960	75.00	75.08
XGA 1	1024 x 768	48.36	60.00	MAC	1280 x 1024	80.00	75.08
XGA 2	1024 x 768	68.677	84.997	WXGA 1	1366 x 768	48.36	60.00
XGA 3	1024 x 768	60.023	75.03	WXGA 2	1360 x 768	47.70	60.00
XGA 4	1024 x 768	56.476	70.07	WXGA 3	1376 x 768	48.36	60.00
XGA 5	1024 x 768	60.31	74.92	WXGA 4	1360 x 768	56.16	72.00
XGA 6	1024 x 768	48.50	60.02	UXGA 1	1600 x 1200	75.00	60.00
XGA 7	1024 x 768	44.00	54.58	UXGA 2	1600 x 1200	81.25	65.00
XGA 8	1024 x 768	63.48	79.35	UXGA 3	1600 x 1200	87.50	70.00
XGA 9	1024 x 768 (Interlace)	36.00	87.17	UXGA 4	1600 x 1200	93.750	75.00
XGA 10	1024 x 768	62.04	77.07	720p	(Progressive)	45.00	60.00
XGA 11	1024 x 768	61.00	75.70	1035i	(Interlace)	33.75	60.00
XGA 12	1024 x 768 (Interlace)	35.522	86.96	1080i/60	(Interlace)	33.75	60.00
XGA 13	1024 x 768	46.90	58.20	1080i/50	(Interlace)	28.125	50.00
XGA 14	1024 x 768	47.00	58.30				

ON-SCREEN DISPLAY	RESOLUTION	H-Freq. (kHz)	V-Freq. (Hz)	ON-SCREEN DISPLAY	RESOLUTION	H-Freq. (kHz)	V-Freq. (Hz)
D-VGA	640 x 480	31.47	59.94	D-SXGA1	1280 x 1024	63.98	60.02
D-480p	720 x 480 (Progressive)	31.47	59.88	D-SXGA2	1280 x 1024	60.276	58.069
D-575p	768 x 575 (Progressive)	31.25	50.00	D-UXGA	1600 x 1200	75.00	60.00
D-SVGA	800 x 600	37.879	60.32	D-720p	1280 x 720 (Progressive)	45.00	60.00
D-XGA	1024 x 768	43.363	60.00	D-1035i	1920 x 1035 (Interlace)	33.75	60.00
D-WXGA1	1366 x 768	48.36	60.00	D-1080i/60	1920 x 1080 (Interlace)	33.75	60.00
D-WXGA2	1360 x 768	47.70	60.00	D-1080i/50	1920 x 1080 (Interlace)	28.125	50.00
D-WXGA3	1376 x 768	48.36	60.00				

When a input signal is digital from DVI terminal, refer to chart below.

Proper image may not be obtained in some signals. Specifications are subject to change without notice.

# **Technical Specifications**

Projector Type	Multi-media Projector
Dimensions (W x H x D)	-
Net Weight	20.39" x 9.92" x 23.86" (518mm x 252mm x 606mm) (Not including adjustable feet) 54.3 lbs (24.7kgs)
0	0° to 3.65°
Feet Adjustment	0 10 3.05
Panel Resolution	
LCD Panel System	1.4" TFT Active Matrix type, 3 panels
Panel Resolution	1024 x 768 dots
Number of Pixels	2,359,296 (1024 x 768 x 3 panels)
Signal Compatibility	
Color System	PAL, SECAM, NTSC, NTSC4.43, PAL-M, PAL-N
High Definition TV Signal	480i, 480p, 575i, 575p, 720p, 1035i, and 1080i
Scanning Frequency	H-sync. 15 ~ 120 KHz, V-sync. 48 ~ 120 Hz
Optical Information	
Projection Image Size (Diagonal)	Subject to Optional lens
Projection Lens	Option
Throw Distance	Subject to Optional lens
Projection Lamp	300W
Interface	
Input 1 terminals	DVI-D Terminal (Digital in) (HDCP Compatible) x1, (VGA) HDB15 Terminal X 2 (Analog In
	Analog Out) and Mini Jack (stereo) x 1
Input 2 terminals	BNC Type x 5 (G/ VIDEO/Y, B/ Cb/Pb, R/ Cr/Pr, H/V, V) and Mini Jack (stereo) x 1
Input 3 terminals	RCA Type x 3 (VIDEO/Y, Cb/Pb, Cr/Pr), Mini DIN 4 pin x 1 (S-Video) and RCA Type x 2
	(Audio R and L(mono))
Input 4 terminals	DVI-D Terminal (Digital in) (HDCP Compatible) x1, Serial port In (DB9) x 1 and Serial port Out (DB9) x1
Other Terminals	Sena por Out (DB3) X1
SERIAL PORT IN	DB9 pin x 1
SERIAL PORT OUT	DB9 pin x 1
USB Connectors	USB Series A receptacle x 1 and USB Series B receptacle x 1
R/C Jack	Mini Jack x 1
Audio	
Internal Audio Amp	3.0W RMS
Built-in Speaker	2 speaker, ø2.05" (52mm)
Power	
Voltage and Power Consumption	AC 100 ~ 120 V (9.5 A Max. Ampere), 50 / 60 Hz (The U.S.A and Canada) AC 200 ~ 240 V (4.5 A Max. Ampere), 50 / 60 Hz (Continental Europe)
Operating Environment	
Operating Temperature	41 °F ~ 95 °F (5 °C ~ 35 °C)
Storage Temperature	14 °F ~ 140 °F (-10°C ~ 60 °C)
Remote Control	
RF Remote Standard	2.4 GHz Low Power Radio
Frequency Band	2.472GHz (CH1: default setting), 2.403GHz (CH2), 2.446 GHz (CH3), and 2.421GHz (CH4
Battery	AA, UM3 or LR6 1.5V ALKALINE Type x 2
Operating Range	Within 32.8' (10m)
Dimensions	2.0" x 1.2" x 7.1" (50mm x 30mm x 181mm)
Net Weight	0.33 lbs (150 g) (including batteries)

#### Accessories

Owner's Manual AC Power Cord Remote Control and Batteries DVI-D Cable VGA Cable Wired Remote Cable Lens Attachment Light Block Plates (2types) Advanced Screen Manager (CD-ROM) Real Color Manager Pro (CD-ROM) Protective Dust Cover Cord Cover Strap Security Label (PIN Code/USB Key)

• The specifications are subject to change without notice.


- LCD panels are manufactured to the highest possible standards. Even though 99.99% of the pixels are effective, a tiny fraction of the pixels (0.01% or less) may be ineffective by the characteristics of the LCD panels.
- The On-Screen Menu and figures in this manual may differ slightly from the product.


# **Optional Parts**

The parts listed below are optionally available. When ordering those parts, give the item name, Model No. and Option Control No. (if necessary) to the sales dealer.

	Model No.
Projector USB Key	: EUB-100
Smoke Resist Box	: AH-69601
Optional Interface Board	Model No.
Advanced Network	: AH-72143 (Option Control No. 06)
Dual SDI	: AH-72162
Faroudja	: AH-72091
DVI (HDCP compatible)	: AH-72003
D-Sub	: AH-72031

# Menu Tree









INFORMATION Input System Signal Screen Language Lamp mode Lamp status Power management Shutter management Shutter time Security Remote control Quit





# Dimensions


Unit : inch (mm)



# **Terminal Configurations**


## ANALOG INPUT / OUTPUT TERMINAL (ANALOG)

Terminal : HDB15-PIN




1	Red (R/Cr) Input / Output	9	
2	Green (G/Y) Input / Output	10	Ground (Vert.sync.)
3	Blue (B/Cb) Input / Output	11	Ground /
4		12	
5	Ground (Horiz.sync.)	13	Horiz. sync. Input/Output (Composite H/V sync.)
6	Ground (Red)	14	Vert. sync.
7	Ground (Green)	15	
8	Ground (Blue)		

### *DVI-D TERMINAL (DIGITAL)* Terminal : DVI-D




1	T.M.D.S. Data2–	9	T.M.D.S. Data1–	17	T.M.D.S. Data0-
2	T.M.D.S. Data2+	10	T.M.D.S. Data1+	18	T.M.D.S. Data0+
3	T.M.D.S. Data2 Shield	11	T.M.D.S. Data1 Shield	19	T.M.D.S. Data0 Shield
4	No Connect	12	No Connect	20	No Connect
5	No Connect	13	No Connect	21	No Connect
6	DDC Clock	14	+5V Power	22	T.M.D.S. Clock Shield
7	DDC Data	15	Ground (for +5V)	23	T.M.D.S. Clock+
8	Analog Vert. sync	16	Hot Plug Detect	24	T.M.D.S. Clock-

#### SERIAL PORT IN /OUT TERMINAL Terminal : DIB 9-PIN




	Serial
1	
2	RXD
3	ТХD
4	
5	GND
6	
7	
8	
9	

## USB CONNECTOR (Series B) Series B




# PIN Code Number Memo

Write down the PIN code number in the column below and keep it with this manual securely. If you forgot or lost the number and unable to operate the projector, contact the service station.



### While the projector is locked with the PIN code or USB key...

Put the appropriate label (supplied) on in a prominent place of the projector's body while it is locked with a PIN code.



The CE Mark is a Directive conformity mark of the European Community (EC).



This symbol on the nameplate means the product is Listed by Underwriters Laboratories Inc. It is designed and manufactured to meet rigid U.L. safety standards against risk of fire, casualty and electrical hazards.

# Index

IN	u	m	е	rı	С	S
	~		-		-	-

2:2 Pulldown	
2:3 Pulldown	47
	20
-	
-	
Appendix	70
Aspect setting	
Auto PC Adjust	41
Auto PC Adjustment	31
-	
Dece	50
Brightness	45
Capture	
Carrying Handle	
, .	
0	
-	
-	
-	
-	
Compatible Computer Specifications	72
COMPONENT	40
Connecting to Computer	
	00
Dimensions	74, 79
Display	54
Dual SDI	75
DVI-D	12, 13, 80
	-
Factory default	58
	2:3 Pulldown         AC plug type         AC Power Cord         Accessories         Adjustable Feet         Analog out         Appendix         Aspect setting         Auto PC Adjust         Auto PC Adjust         Auto PC Adjustment         Auto PC Adjustment         Auto PC Adjustment         Auto picture control         AV System         Bass         Baud rate         Brightness         Capture         Carrying Handle         Ceiling         Ceiling Mount         Cinema         Cleaning         Color Management List         Color Management List         Color System         Color Selection         Color System         Color temp.         Connecting to Computer Specifications         COMPONENT         Connecting to Digital PC/AV Equipment         Contrast         Control Pad         Cord Cover Strap         D-Zoom         Dimensions         Display         Dual SDI         DVI-D

	Fan control		.59
	Faroudja		.75
	Federal Communication Commission Notice		8
	Film	2.	47
	Filter		
	Filter Indicator		
	Focus		
	Freeze		
	Front cover		
	Full screen		
0			.40
G			
	Gamma		.47
Н			
	H&V		.48
	Handling the Projector		
	HDB15-PIN		.80
L			
	Image		.44
	Image Adjust		.45
	Indicators	.10,	67
	Information	.31,	61
	Input		
	Input Search		
	Installation		
	Interface		
	Interface Board		
к			
IX.	Keylock		56
	Keystone		
	Reystone	32,	43
L			
	Lamp		
	Lamp Control		
	Lamp Mode		
	Lamp Replace Indicator		
	Lamp Replacement		
	Language		
	Lens Installation		
	Lens memory		
	Lens Shift		
	Logo		
	Logo Lock		.52
	Logo PINcode		.52
	Logo Select		.52
Μ			
	Manual PC Adjust		.42
	Menu		
	Menu Icons		
	Menu Position		

	Menu Tree	76
	Mouse Operation	-
	Moving the Projector	
	Mute	
	My Menu	
	My menu	
Ν		75
	Network Manager	
~	Normal	
0	On start	E /
	On-Screen Menu	
	Optional Parts	
Р		0
Г	P-Timer	30
	Panel Besolution	
	Parts Name	
	PC Adjustment	
	PC System	
	PIN code	
	PJ lock	57
	Position	
	Positioning	6, 18
	Power management	54
	Progressive	
	Projector Condition	
_	Projector ID	60
R		
	Radio Wave	
	READY indicator	
	Real	
	RearReference Buttons	
	Remote Control	
	Remote control	
	Remote Control Battery Installation	
	Remote Control Channel and ID	
	REPLACEMENT LAMP	63, 65
	RESET	
	RS-232C	60
S		
	Scale	
	Scanning Frequency	74
	Screen	32, 48
	Security	56
	SERIAL PORT	13, 80

	Setting	51
	Shutter	.2, 30, 55
	SHUTTER indicator	10
	Shutter Indicator	68
	Shutter level	55
	Shutter Management	56
	Shutter protection	
	Simple menu	51
	Smoke Resist Box	75
	Sound	50
	Speaker	9
	Special	59
	Specifications	74
Т		
	Telecine	47
	Terminal Configurations	80
	Terminals	12, 21
	Test pattern	60
	Top Control	9, 11
	Treble	50
	Troubleshooting	70
	True	48
	Turning Off the Projector	29
	Turning On the Projector	28
U		
	USB CONNECTOR	80
	USB Key	75
	USB lock	56
	USB memory	60
V		
	Volume	33, 50
w	,	
	Warning log	61
	WARNING TEMP indicator	
	Warp & Blending	
	Wide	
	Wired Remote Control	16, 26
z		
_	Zoom	
		,



#### A-key to better communications

#### U.S.A.

EIKI International, Inc. 30251 Esperanza Rancho Santa Margarita CA 92688-2132 U.S.A. Tel : 800-242-3454 (949)-457-0200 Fax : 800-457-3454 (949)-457-7878 E-Mail : usa@eiki.com

### Deutschland & Österreich

EIKI Deutschland GmbH Am Frauwald 12 65510 Idstein Deutschland Tel : 06126-9371-0 Fax : 06126-9371-14 E-Mail : info@eiki.de

#### Canada

EIKI CANADA - Eiki International, Inc. P.O. Box 156, 310 First St. - Unit 2, Midland, ON, L4R 4K8, Canada Tel : 800-563-3454 (705)-527-4084 Fax : 800-567-4069 (705)-527-4087 E-Mail : canada@eiki.com

### **Eastern Europe**

EIKI CZECH spol. s.r.o. Umělecká 15 170 00 Praha 7 Czech Republic Tel : +42 02 20570024 +42 02 20571413 Fax : +42 02 20571411 E-Mail : easterneurope@eiki.de

### Japan & Worldwide

EIKI Industrial Company Limited. 4-12 Banzai-Cho, Kita-Ku, Osaka, 530-0028 Japan Tel : +81-6-6311-9479 Fax : +81-6-6311-8486 E-Mail : japan@eiki.com

## WorldWide Website http://www.eiki.com