



customer c 0xFF00

Function Function Code

POWER	0x00
UP	0x01
Left	0x03
Menu	0x04
right	0x05
enter	0x06
down	0x07
keystone+	0x09
keystone-	0x0A
auto	0x0B
volume+	0x0C
volume-	0x0D
4/3 16/9	0x0E
source	0x0F
mute	0x10
blank	0x11