

## LC-HDT1000 IR Command List

Transmission format of projector operation key

: NEC Format (single command / command pipelining mode)

Custom Code + Custom Code

: 8 patterns as below

33h+00h(Default; code1), 33h+11h(code2), 33h+22h(code3), 33h+33h(code4),

33h+44h(code5), 33h+55h(code6), 33h+66h(code7), 33h+77h(code8)

Key No.	Data Code (HEX)	Function
1	11	ON
2	10	STAND-BY
3	8B	SHUTTER
4	--	LIGHT
5	82	SCREEN
6	1C	MENU
7	89	AUTO PC
8	8C	CURSOR UP
9	1E	CURSOR LEFT
10	0F	SELECT
11	1D	CURSOR RIGHT
12	8D	CURSOR DOWN
13	40	LENS SHIFT
14	0C	IMAGE ADJUST
15	47	ZOOM +
16	4A	FOCUS +
17	0D	IMAGE SELECT
18	46	ZOOM - (Number 1)
19	4B	FOCUS - (Number 2)
20	38	INPUT 1 (Number 3)
21	43	FREEZE (Number 4)
22	88	D. ZOOM (Number 5)
23	39	INPUT 2 (Number 6)
24	8A	P-TIMER (Number 7)
25	5B	KEystone (Number 8)
26	06	INPUT 3 (Number 9)
27	1A	FILTER
28	16	INFORMATION (Number 0)
29	08	INPUT 4
30	07	PIP
--	00	ON-OFF