

EIKI:LC-XB100/100A/200/200A IR Command List

- Transmission format of LCD projector operation key
: NEC Format (single command / command pipelining mode)
- Transmission format of PC mouse operation button (mouse cursor button) / L / R key
: Interlink Mouse Code Format (Includes 3 bit of ID)
- Format for the transmission of OSD Laser operation button (mouse cursor button)
: Interlink OSD Mouse Code Format (Includes 3 bit of ID)
- Custom Code + Custom Code
: 8 patterns as below
33h+00h(Default; code1), 33h+11h(code2), 33h+22h(code3), 33h+33h(code4),
33h+44h(code5), 33h+55h(code6), 33h+66h(code7), 33h+77h(code8)

Key No.	Data Code (HEX)	Function
1	*1	L-CLICK Back-side Click Trigger Key
2	00	ON-OFF
3	38	COMPUTER
4	05	VIDEO
5	16	INFORMATION
6	5B	KEYSTONE
7	17	AUTO SET
8	8C	CURSOR UP
9	1E	CURSOR LEFT/VOLUME -
10	1D	CURSOR RIGHT/VOLUME +
11	8D	CURSOR DOWN
12	1C	MENU
13	0F	SELECT
14	*1	R-CLICK
15	43	FREEZE
16	84/85 *2	LASER
17	8B	NO SHOW
18	59	PAGE +
19	01	D.ZOOM +
20	8A	P-TIMER
21	5A	PAGE -
22	02	D.ZOOM -
23	0B	MUTE
24	18	LAMP CONTROL
25	82	SCREEN
26	0C	IMAGE
OB1	*1	MOUSE CURSOR BUTTON

*1... Transmit code for Mouse *2... Transmit code to set Laser Pointer / OSD Laser to ON/OFF