

2007/11/14

LC-XT9(SANYO : PLC-XF42) IR Command List

- Transmission format of LCD projector operation key
: NEC Format (single command / command pipelining mode)
- Custom Code + Custom Code
: 8 patterns as below
33h+00h(Default; code1), 33h+11h(code2), 33h+22h(code3), 33h+33h(code4),
33h+44h(code5), 33h+55h(code6), 33h+66h(code7), 33h+77h(code8)

Key No.	Data Code (HEX)	Function
1	--	LIGHT
2	00	ON-OFF
3	89	AUTO PC
4	1C	MENU
5	8B	NO SHOW
6	8C	CURSOR UP
7	1E	CURSOR LEFT/VOLUME -
8	0F	SELECT
9	1D	CURSOR RIGHT/VOLUME +
10	8D	CURSOR DOWN
11	40	LENS SHIFT
12	0C	IMAGE ADJUST
13	47	ZOOM +
14	4A	FOCUS +
15	38	INPUT 1
16	46	ZOOM -
17	4B	FOCUS -
18	39	INPUT 2
19	43	FREEZE
20	88	D. ZOOM
21	06	INPUT 3
22	8A	P-TIMER
23	5B	KEYSTONE
24	08	INPUT 4
25	0D	IMAGE SELECT