



EIKI S1002 series

Remove the Lens Shift Cover


1



2



3



4

